

# PERLEGEAR

## FREQUENTLY ASKED QUESTIONS

## QUESTION How can I level the TV after installation?

If the TV brackets and TV are properly installed, but the TV is still not level:  
Slightly loosen the bolts. Level your TV. Retighten the bolts to hold the TV in position.



### Note:

Do not overtighten or overloosen.

