



by Stevens Industries, Inc.
704 West Main St.
Teutopolis, IL 62467
P: 800.350.3270
P: 217-857-7100
F: 217-857-7101
www.totmate.com

TM2125R
TM2127R
TM2128R

Toddler Play Center



TM2125R
HARDWARE BAG# 0563-3304

Preschool Play Center



TM2127R
HARDWARE BAG# 0563-3304

Preschool Play Center



TM2128R
HARDWARE BAG# 0563-3304



CAUTION – CHOKING HAZARD

Adult assembly required due to presence of small parts and sharp edges.

ATTENTION

Please unpack and assemble in an area away from children's activities. Remove all tools and excess materials from work area after assembly of unit is complete. Dispose of pallet and packaging materials in an environmentally friendly manner. If any parts are missing or damaged, please call Stevens for immediate parts replacement (1-800-350-3270). When ordering parts, give the Model Number and Color of the unit.

Illustrations and part numbers are for TM2125R

Basic assembly instructions are the same for models shown. 2-Person assembly recommended.

IMPORTANT!

Be sure to keep all parts supported during assembly to avoid damage. Do not over-tighten bolts or it will damage the pre-drilled holes. Snug fit is adequate.

NOTE: Refer to exploded drawing for orientation of holes to parts.

HARDWARE / TOOLS INCLUDED

(Phillips screwdriver required but not included.)



Confirmat Bolt (5)
(Screw Conn HxDc Ni
7mmx50mm)



Hex Wrench

PARTS for TM2125R

ITEM	QTY	DESCRIPTION
1	1	Top
2	1	Bottom
3	2	End
4	1	Rail Support
5	2	Lego Plate, Large Gray LGP50x50
6	3	Tray, Clear 6in F/2 SA911
7	10	Screw Conn HxDc Ni, 7mm x 50mm
8	4	Gear Block, Totmate Red 7x7

- STEP 1:** Lay one **End (1)** flat on floor, with side having the most holes facing up.
NOTE: Raw edge is top edge.
- STEP 2:** Insert dowel on **Rail Support (4)** into lower hole at top of **End (3)**. Press firmly into place.
- STEP 3:** Insert dowels on one end of **Bottom (2)** into remaining holes on **End (3)**. Press firmly into place.
- STEP 4:** Position other **End (3)** on top of assembly, so dowels on **Rail Support (4)** and **Bottom (2)** align with holes on **End (3)**. Press firmly in place.
- STEP 5:** Secure **End (3)** to **Rail Support (4)** and **Bottom (2)** with three **Confirmat Bolts (10)** using included **Hex Wrench**.
- STEP 6:** Carefully turn assembly over, so other **End (3)** is facing up.
- STEP 7:** Repeat **Step 5** to secure **End (3)** to **Rail Support (4)** and **Bottom (2)**.
- STEP 8:** Carefully stand unit upright and align holes in **Top (1)** with dowels on top edge of **Ends (3)**, making sure the pre-installed **Lego Plate (5)** is facing up. Press **Top (1)** firmly into place.
- STEP 9:** Secure **Top (1)** to **Ends (3)** with four **Confirmat Bolts (10)**.
- STEP 10:** The 4-piece **Gear Block Grid (8)** fits onto the **Lego Plate (5)**, or can be set aside for later use. **Trays (6)** are included for storage on lower shelf.
- STEP 11:** Ensure that all joints and bolts are tight.
This completes the assembly.

