

Saros Z70 Robotic Arm Operation Guide

What Can the Robotic Arm Do?

- Remote Control Pick Up
- Sort Items
- Follow-up Cleaning
- Switch Between Robot Camera and Robotic Arm Camera during Remote Viewing

First-Time Setup: Enable the Robotic Arm

You need to enable the robotic arm function before first use.

(1) (3)

Emergency Stop Button
Power Button

When the robotic arm is inside its compartment:

Pressandholdboththe Emergency Stop Button and the Power Button to

enable or disable the robotic arm function.

(Note: This only enables or disables the robotic arm. To deploy it, please use the app.)

By the way, when the robotic arm is outside its compartment:

- Pressthe Emergency Stop Button to immediately stop the robotic arm.
- Pressandholdboththe Emergency Stop Button and the Power Button to reset the robotic arm.

(The robotic arm will return to its compartment, and the Electric Hatch will close.)

Please refer to the attached video for guidance: https://youtu.be/tX6-pCwVwNs



First Function: Sort Items


Add Storage Zones

To sort items, first add Storage Zones on the map.

Go to the home page, tap the Edit button, and add **Shoe Storage Zone** and **Roborock Storage Box**. Adjust their size and position, then tap **Save**.

Note:

- 1. Aphysicalstorageboxisincludedinthepackage. Place it at the physical location matching the Fabric Storage Zone.
- 2. Thestorageboxprovidedfortherobotismadeofintegratedcardboardand needs to be folded and assembled into a box. Please refer to the attached video for guidance: https://youtube.com/shorts/EqnP8aDcc88




Automatic Sorting

You can organize items either by automatic sorting or manual sorting — both methods work, so just pick the one that suits you best!

To turn on automatic sorting, go to **Settings > Robotic Arm Setting >** switch on **Automatic Sorting**.

Once it's enabled, the robot will start sorting items automatically during its cleaning tasks.

You can watch the video tutorial here: https://youtu.be/y6LrSgx3DUk



Manual Sorting


Turn off Automatic Sorting first.

There are two ways to start **Manual Sorting**, and you can use either one:

- 1. Tap**SortingItems**onthehomepage.
- 2. OrgotoSettings>RoboticArmSetting>ManualSorting.


Select items icon and then tap Start Sorting.

You can watch the video tutorial here: https://youtu.be/CmH_TEONxVs



Alternatively, you can tap the obstacle icon directly on the map. You will see a **Sorting** option. Tap it to have the robot sort the selected item.

Note: This method is only applicable for sorting a single item.




Second Function: Remote Control to Pick Up

You can control the robotic arm to pick up items remotely.

On the main map page, tap the **robotic arm icon** to enter the **Remote Viewing** page. Then tap **Remote Control to Pick Up** at the bottom right to access the control interface.

Note: A 2-way video call feature is also available on this page, but this section focuses on Remote Control to Pick Up.



Automatic pick up

Auto Pick Up includes two stages:

Pick Up and Put Down.

Pick Up

- 1. Move the robot until the item is positioned inside the blue zone.
- 2. Tap **Start Picking Up**. The robotic arm will automatically grip the item.
- 3. If needed, tap Pause to either Continue Picking Up or End Picking Up.



Put Down

After successfully picking up the item, move the robot to a clear area. Tap **Put Down** to release the item.



You can watch the video tutorial here: https://youtu.be/PykRa9Q5E-c

Manual pick up

Tap the robotic arm icon on the main map to open the *Remote Control to Pick Up* page, then switch to **Manual** mode.

There are two ways to control the arm: Arm Motion and Joint.

- ArmMotioncontrolstheM5jointandtheendclaw—it'ssimplerandquickerto use.
- **Joint**givesyoufinercontroloverM3,M4,andtheendclaw.(Youcancheckthe diagram below for reference.)

In both control modes, you'll see three control columns:

•

- Left:Turntheclaw(endeffector)indifferentdirections.
- Middle:Movethearmorjointsupanddown.

Right: Move the armorjoints forward and backward.


At the bottom, you'll find two buttons:


Aclosedclawicon=PickUpanitem.

Anopenclawicon=PutDownanitem.

You can watch the video tutorial here: https://youtu.be/_l9xc6bPfN8







Third Function: Switch Between Robot Camera and

Robotic Arm Camera

In 'Remote Control to Pick Up page', tap the camera icons to switch between the robot's main camera and the robotic arm camera.

You can also adjust the arm and joint positions on the Manual Pick Up page to change the robotic arm camera's viewing angle.

You can watch the video tutorial here: https://youtu.be/IWyT4Cvc1yQ



Forth Function: Follow-up Cleaning

The robot uses the robotic arm to move small items out of the way to clean

underneath, helping prevent missed spots.

Supported items include fabrics (socks, dust cloths), paper balls, and shoes (slippers, low-top shoes).

Enable it via Settings > Robotic Arm Settings > Follow-Up Cleaning.

Once enabled, the robot will perform this action automatically during cleaning: no manual operation needed.

You can watch the video tutorial here: https://youtu.be/CPToEHqLmas

