



M30 Wired Controller for Xbox

English




M30 有线手柄 (Xbox)

中文




Xbox Series X|S or Xbox One

* The latest firmware version of your Xbox console is required.
Connect the controller to your Xbox console via its USB cable, and wait till the **status LED** becomes solid to play.




Xbox Series 系列 / Xbox One 系列主机

* 要求 Xbox 主机系统已更新到最新版本。
将手柄连接到 Xbox 主机的 USB 端口, **状态指示灯** 常亮后即可使用。




Windows 10 / Windows 11

* System requirement : Windows 10(1903) or above.
Connect the controller to your Windows device via its USB cable, and wait till the **status LED** becomes solid to play.




Windows 10 / Windows 11

* 要求 Windows 设备系统版本为 Windows 10 (1903) 或更高版本。
将手柄连接到 Windows 主机的 USB 端口, **状态指示灯** 常亮后即可使用。




Volume Control

- * Emits a beep when adjusted to maximum, middle, or minimum value.
- * Press and hold **profile + up/down** to turn up/down in-game volume.



- * Press and hold **profile + left/right** to adjust the balance between voice and game volume.




Safety Warnings

- * Please always use batteries, chargers, and accessories provided by the manufacturer.
- * The manufacturer is not liable for any safety issues arising from the use of non-manufacturer-approved accessories.
- * Do not attempt to disassemble, modify, or repair the device yourself. Unauthorized actions may result in serious injury.
- * Avoid crushing, disassembling, puncturing, or attempting to modify the device or its battery, as these actions can be dangerous.
- * Any unauthorized changes or modifications to the device will void the manufacturer's warranty.


声音调节

- * 可通过组合键调整耳机的音量与声音平衡, 调整到最大 / 最小 / 中间值时会有提示音。

1. 按住 **配置键 + 方向键上**, 下可提高、降低主音量。



2. 按住 **配置键 + 方向键左、右** 可调节语音、游戏之间的音量平衡



安全警示

- * 请使用制造商的电池、充电器、配件。
- * 在用户使用第三方的配件时, 制造商不能对用户的安全负责。
- * 请勿自行拆卸、改装或修理设备。
- * 请勿挤压、拆解、刺穿或尝试改装设备及电池。
- * 对设备的任意变动或改装, 将导致制造商对设备不予保修。

Ultimate Software

- * Press the **profile** button to activate/deactivate the custom profile. The profile indicator will not light up when using the default setting.
- * Please visit app.8bitdo.com for 8BitDo Ultimate Software X, which gives you elite control over every piece of your controller.

自定义配置

- * 配置后按下 **配置键** 可开启 / 关闭 / 切换不同的配置, 默认无配置。
请访问 app.8bitdo.cn 获取精英软件 X, 可对手柄按键映射等功能进行自定义配置。

Support

Please visit support.8bitdo.com for further information & additional support.

技术支持

* 请访问 support.8bitdo.cn 了解详细信息。