


English

RGB LED Wall Clock

(Alarm Clock/Timer/11 color Digits Display/Hourly Chime Funtion)


Thank you for your purchasing,
Please read instruction before set up.



Choose time system (12/24 time format), Used as "+" when setting the time and date; Used as a button to add minutes in "Timer" mode.

Set up years, date, time ; Used as a button to add hour in "Timer" mode.

Color Switch, Color Selection ; In alarm clock mode, it is the SNOOZE function key ; Treated as a start/pause button when using a timer.



Brightness Adjustment:
High Brightness/Auto-dimming/Low Brightness.

When used as a timer, press these two buttons at the same time to clear.
Timer mode.

Enter the timer function, timer mode selection.

Change thermometer system (°C/°F Format), Used as "-" when setting the time and date;
Used as a button to add seconds in "Timer" mode.


1. language/DST/Years/Date/Time Set Up

- ① Press "SET" button to start.




Once you press it, you will see "ENG" keep flashing on the screen, you can change to the other language by press "+" or "-".

- ② Setting up DST, years, date, time with "+" "-" and "SET" button ("SET" button as "Confirm" button).



If the date is entered correctly, the day will auto format.

- ③ Press "SET" button to the time display after all settings are completed.



2. Date and Temperature Display Format Switch

- ① Pressing "+" button around 2 seconds to setting display mode.




MONTH TEMP DATE: Display Month Date and Temp every 5s in turns.

MONTH DATE: Display Month Date without Temp.

TEMP : Display Temperature only.

- ② Press "+" button to switch display format as showing in the following.



- ③ Treat "SET" button as "Confirm" button when setting.



3. Alarm Set Up

- ① Press "Alarm Set" button for set up.



- ② Alarm Choosing.



("AL1" flashes at the bottom of the screen. Press "SET" button for next step) (AL1 is only option).

- ③ Alarm turn ON/OFF.



Press "+" "/" "-" to make alarm ON/OFF, then press "SET" as "Confirm".

- ④ Alarm time setting.



Press "+" "/" "-" to set up alarm time, then press "SET" as "Confirm".

- ⑤ Alarm working day mode.



(Press "+" "/" "-" to choose the mode):
Alarm running
1E: Everyday;
2E: Mon-Fri;
3E: Sat-Sun.

- ⑥ Press "SET" button when you finish.




* SNOOZE and Intelligently Turn Off Alarm

- ① Snooze Function.



Once alarm ringing, press "SNOOZE" button to stop it but will ringing again after 9 minutes.

- ② Intelligently turn off alarm with any keys.



When alarm rings, press any of these 5 buttons to turn it off but will ring up again for next day.

4. Timer Set Up On Wall Clock

* -T1-T8 Timing range: 0:00:00-29:59:59.


* -T9 long timing range: 39 days 23 hours 59 minutes 59 seconds.

* -Automatically save the last timing when starting up (with a memory battery).

* -Once finish timing, "BIBI" sounds up about 90 seconds.

Count Down setting


- ① Press "Timer" button to start timing mode.



- ② Display turns to timing mode.




- ③ Setting up timer to count down.




- ④ The button for start/pause.



- ⑤ Press these two buttons together to clear, then it will display 0:00:00.



- ⑥ Press the "Timer" button to switch to the next set of timing modes, until you return to the time display.




Count Up setting

- ① Press "Timer" button to start timing mode.



- ② Press these two buttons together to clear, then it will display 0:00:00.



- ③ Press "SNOOZE" button to start count up.




5. Hourly Chime Set Up

- ① Keep pressing "Alarm Set" button for 2 seconds to start, then press "+" or "-" to choose ringtone.




(There are 3 ringtones)
S1: AVE MARIA + CHIME
S2: WESTMINSTER ABBEY + CHIME
S3: CHIME

- ② Press "SET" to set up time range for hour ringing, press "+" "/" "-" to choose the mode.



MOD 1: Not chime
MOD 2: Hourly chime
Mode3: Chime from 6:00 to 21:00

Large Digital Wall Clock with Remote Control



MADE IN CHINA



Please use the
attached adapter



RGB LED Wall Clock
MANUAL

SUITABLE FOR LIVING ROOM/OFFICE/CLASSROOM/HOSPITAL/SUBWAY PLACES

