



Original	Replacement
	 Power
	 Green / APP / Repeat
	 TV/Radio /
	 Yellow / YouTube / Repeat
	 Info / Angle
	 Blue / Prime Video / Random
	 Guide / EPG / -/--
	 Red / Netflix / Search
	 Up
	 Display / Media
	 Text / Goto
	 Exit / Cancel / Clear
	 Left
	 I<< / Preset-
	 OK
	 Right
	 >>I / Preset+

Original	Replacement
	 Menu / Home
	 Vol+
	 Down
	 CH+ / Page+
	 Vol-
	 Mute / Dimmer
	 CH- / Page-
	 1
	 2
	 3
	 Fav / Marker / PC
	 4
	 5
	 6
	 Shift + Exit / Cancel / Clear
	 7
	 8







Original	Replacement
 Power	 Power
 Green / Prog.	 Green / APP / Repeat
 Green / Prog.	 TV/Radio /
 Yellow / Status	 Info / Angle
 Yellow / Status	 Yellow / YouTube / Repeat
 Blue / Guide	 Blue / Prime Video / Random
 Blue / Guide	 Guide / EPG / -/--
 Red / Dec.	 Red / Netflix / Search
 Up	 Up
 Purple / Text	 Display / Media
 Purple / Text	 Text / Goto
 Exit	 Exit / Cancel / Clear
 Left / I<<	 I<< / Preset-
 Left / I<<	 Left
 OK	 OK
 Right / >>I	 Right
 Right / >>I	 >>I / Preset+

Original	Replacement
 Menu	 Menu / Home
 Vol+	 Vol+
 Down	 Down
 PR+	 CH+ / Page+
 Vol-	 Vol-
 Mute	 Mute / Dimmer
 PR-	 CH- / Page-
 1	 1
 2	 2
 3	 3
 Index / Mark	 Fav / Marker / PC
 4	 4
 5	 5
 6	 6
 0000	 Shift + Exit / Cancel / Clear
 7	 7
 8	 8



