

NOTE:


This brochure contains IMPORTANT safety info. Please read and keep for future reference.

MAINTAINANCE AND WARNING


- 1. Keep furniture away from heat sources.
- 2. Do not clean furniture with harsh cleaner or polishes. Do not use detergents, solvents, abrasives, spray packs or leather cleaner. Use non-color mild soap with warm water to clean spills (Mix 1:10 soap to water).
- 3. Do not place furniture under direct sunlight, material will possibly fade over time.
- 4. Do not use on site dry cleaning machine. Children should not climb or jump on the furniture.
- 5. Do not write on furniture that is not protected by a padded barrier.
- 6. Not for commercial use, only for residential use.




EXPLOSIVE VIEW




PARTS LIST





HARDWARE LIST




HARDWARE SPARE LIST














06/15































ASSEMBLY INSTRUCTIONS




















WARRANTY

- 1. We strive to offer high-quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed.
- 2. We provide 30 days warranty starting from the time you receive the item. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive.
- 3. Replacement parts by purchasing them with our company if they are available.