



BOOM 3

INDEX

GETTING STARTED

- [Quick start guide](#)
- [Get started](#)
 - [Use the Magic Button](#)
 - [Adjust volume](#)
 - [Charge your speaker](#)
 - [Check battery level](#)
 - [Connect to more devices](#)
 - [Pairing additional devices](#)
 - [Reconnecting to a device](#)

SPECIFICATIONS

- [CUSTOMIZABLE EQ](#)
- [POWER](#)
- [AUDIO](#)
- [DIMENSIONS](#)
- [WIRELESS CAPABILITIES](#)
- [COMPATIBILITY](#)

FAQs

- [Do I need to clean my speaker after using it in or around water?](#)
- [Can I use my speaker to make phone calls?](#)
- [Does my speaker have a voice assistant feature?](#)
- [Can I stream music through the auxiliary port?](#)
- [The app does not recognise the speaker in iOS 13](#)
- [Music drops out occasionally](#)
- [I can't connect to my device](#)
- [How To Use The Ultimate Ears Boom App](#)
 - [To set up the app for your speakers](#)
- [Setting up Alexa](#)
- [PARTYUP](#)
 - [Volume control](#)
 - [Public settings](#)
- [Trouble logging into Amazon](#)

WARRANTY

- [Hardware warranty](#)

CONTACT US

- [ULTIMATE EARS Support](#)

GETTING STARTED

QUICK START GUIDE

VIDEO: Ultimate Ears BOOM 3 Unboxing and Onboarding: youtu.be/ShMG0okeU6o


GET STARTED

1. Power on the speaker

SHORT PRESS the power button to turn on your BOOM 3.

2. Pair your phone to the speaker

PRESS AND HOLD the Bluetooth® button to put it in the pairing mode.
Go to Bluetooth® setting on your phone and select BOOM 3 to connect.




Use the Magic Button

USE THE MAGIC BUTTON TO CONTROL YOUR MUSIC.


SHORT PRESS to play and pause.

DOUBLE PRESS to skip a track.



Adjust volume


Press the "+/-" button to increase/decrease volume.



Charge your speaker


LIFT THE WEATHER DOOR to charge using the USB cable.

You can also charge your speaker by placing it on POWER UP charging dock (sold separately).



Check battery level

SIMULTANEOUSLY PRESS the "+/-" button to check battery level.



Connect to more devices

Your UE speaker will remember the last eight devices it connected with.

Pairing additional devices

After you pair the first device, here's how to pair additional devices:

1. Turn the speaker on.
2. Hold down the Bluetooth® button until you hear a tone.
NOTE: The Bluetooth® connection button will blink rapidly, indicating that the speaker is ready for pairing.
3. On your device, go to the Bluetooth® menu and scan for devices.
4. Select the name of your speaker from the list of devices.

Once paired and connected, you'll hear an audible confirmation from the speaker. Your speaker is now ready to use with the device you added.

Reconnecting to a device

To reconnect a device to your Ultimate Ears speaker after the initial pairing or after pairing another device:

1. Turn the speaker on
2. On your device, go to the Bluetooth® menu and select the name of your speaker from the list of devices.

Once reconnected, you'll hear an audible confirmation from the speaker. Your speaker is now ready to use with the device you selected.

SPECIFICATIONS

CUSTOMIZABLE EQ

Select the best Sound for different occasions with 4 different presets and a customized tuner.

POWER

Rechargeable Lithium-Ion Battery for up to 20 hours of battery life^{1**} between Micro USB charges.

AUDIO

Maximum Sound Level: 90dBC. Frequency Range: 90Hz – 20kHz. Drivers: Two 2", and 2" x 4" Passive Radiators.

DIMENSIONS

Diameter: 73 mm (2.8").

Height: 184 mm (7.2").

Weight: 602 g (1.34 lb)

WIRELESS CAPABILITIES

Pair up to 8 Bluetooth® enabled source devices – Connect up to two source devices at the same time. Mobile range of play is up to 45 m (150 ft).

COMPATIBILITY

For Audio Playback: Smartphones, tablets and other devices that support Bluetooth® and *BluetoothSmart* wireless audio profile [Advanced Audio Distribution Profile (A2DP)]

^{1**}Actual battery life will vary with use, settings, and environmental conditions.

FAQs

- Do I need to clean my speaker after using it in or around water?

Always thoroughly rinse and dry your speaker, micro-USB port and charging ring with fresh water after using it in a swimming pool or the ocean. While the speaker is waterproof, the chemicals and salt in your pool or the ocean can damage the waterproof seals over time if not rinsed off after use.

- Can I use my speaker to make phone calls?

No, MEGABOOM 3 doesn't support voice calls.

- Does my speaker have a voice assistant feature?

No, MEGABOOM 3 doesn't have a voice assistant feature.

- Can I stream music through the auxiliary port?

No, MEGABOOM 3 doesn't have auxiliary ports.

- The app does not recognise the speaker in iOS 13

After updating to iOS 13, you will need to allow the app to access Bluetooth®. To do so, in your iOS Settings, go to your speaker's app settings and turn on the Bluetooth access.

In case you have installed the app after the iOS update, you will be prompted with a message requesting Bluetooth access for the app. In this case, just click on "OK" to give access.

- Music drops out occasionally

If you're having trouble with audio distortion or drop-outs on your speaker, try these suggestions:

- Move the audio source closer — it might be out of the range of your speaker.
- Move away from other sources of wireless signal (microwave, routers, cordless phones, etc.) — you could be experiencing interference.
- Make sure your speaker has enough battery power (connect it to a power source with the supplied adapter).
- Adjust the volume on both the audio source and your speaker.
- Restart both your speaker and the audio source.
- Re-pair your device with your speaker.

NOTE: If you're streaming audio content from the internet, the issue could be with the internet connection and not your speaker.

- I can't connect to my device

If your Bluetooth® device won't connect to your Ultimate Ears speaker, try the following:

- Make sure your speaker is turned on.
- Make sure your device is paired with your speaker and Bluetooth is active.
- Place your Bluetooth® device closer to the speaker — it might be out of range.
- Move your Bluetooth device and speaker away from other wireless sources — you could be experiencing interference.
- Turn your speaker off, and then back on again.
- If you have multiple speakers, make sure you're connected to the correct one.

NOTE: If this is the first time you're pairing a device with your speaker, you don't need to press the Bluetooth connection button. It comes out of the box ready to pair.

- How To Use The Ultimate Ears Boom App

The Ultimate Ears BOOM app has everything you need to get the most out of your Ultimate Ears speaker. From #PartyUp to customizable EQ, unlock even more awesome ways to use your speakers.

- One App: Use one app to access speaker features for all BOOM and MEGABOOM speakers. Works with BOOM, BOOM 2, BOOM 3, MEGABOOM and MEGABOOM 3, and HYPERBOOM.
- Customize the Name of your Speaker: Have fun with it and make it easier to find in your device list.
- Remote On/Off: You'd never walk all the way to your TV to turn it on and you shouldn't have to with your wireless speaker either. Use the app to turn your speaker on/off from afar.
- One Touch To Your Playlists: Follow the on-screen instructions to select your playlist from Apple Music (iOS only) or Deezer premium (Android Only).

- Adaptive EQ control: (HYPERBOOM only). Turn On or Off this smart EQ feature that automatically adjusts HYPERBOOM's sound signature for the best sound depending on its environment.
- EQ: You Control the Sound: Want to bump up the bass for your next party? Customize your beats in the app. You control the atmosphere with the recommended presets or customize the EQ to your listening preferences.
- PartyUp: Pair up to 150 speakers for the ultimate sound experience. You can pair any BOOM or MEGABOOM together. To pair your speakers together, every speaker must be updated with the latest speaker Firmware (check the app to ensure your speaker has the latest firmware).
- Alarms: Don't be late again. Choose your favorite music to wake up to.
- Speaker Updates: When new software is available for your speaker, a simple tap in the app updates your speaker with the latest features in no time. Your speaker keeps getting better with the in-app updates.

To set up the app for your speakers:

1. Connect your speaker to your smartphone, tablet, or any other device using Bluetooth. For help, see [Connecting your speaker to your device](#).
2. Download the BOOM app from the Google Play store or the App Store.
3. Open the app once it's installed. You'll see a screen with your speaker name, speaker image, the features available for your speaker, and access to speaker settings. You are now ready to use the app to take advantage of all the features of your speaker.

- Setting up Alexa

BLAST and MEGABLAST are all far-field voice-enabled speakers and when turned on, all you need to do is say, "Alexa" and then your request. The speaker will automatically hear you and respond. If the speaker is turned off, you'll need to power it on for the far-field voice capability to work.

They support the following music services:

- Amazon Prime Music
- Amazon Music Unlimited
- Pandora (US)

- Deezer
- TuneIn
- iHeartRadio (US, Australia, New Zealand)
- Spotify

Alexa skills can be enabled from the Alexa app. You can download the app from the iOS App Store or Google Play Store to browse and enable Alexa Skills.

Not sure you are connected. You can check to see if you're connected in three simple ways:

- Check the Ultimate Ears app — tap the Gear icon to get to speaker settings and find the Amazon Alexa section. Tap to sign-in or see what account is associated to your speaker.
- Check your Alexa app and see if your speaker is online. **
- Ask Alexa — say "Alexa, whose account is this?" and she will tell you which account is connected.

** Here's how to check if your speaker is online in the Alexa app:

- Launch the Alexa app.
- Tap the Home icon on the top left (three horizontal lines).
- Tap Settings.
- All of your Alexa-enabled devices should be listed as well as their connectivity status.

If your Amazon account is from a supported country (United States, United Kingdom or Germany), you'll be able to use Alexa regardless of where you travel. Alexa will continue to function when you travel outside of these countries.

- PARTYUP

To join the party, you'll need to get the latest and greatest App and Software for your speakers first.

- iOS App Store
(<https://itunes.apple.com/app/ue-boom/id632344648>)
- Android Play Store
(<https://play.google.com/store/apps/details?id=com.logitech.ueboom>)

Once you have the latest app, you can update your speaker software through the app via OTA (over-the-air). Once you're up on the latest app and speaker software, follow the steps below:

1. Connect the first speaker (host) to your phone or tablet then open your ULTIMATE EARS speaker app.
2. On the home screen of the app, swipe the screen from right to left to get to the PartyUp screen.
3. Guest speakers will start to appear in the drawer (bottom of the PartyUp screen). Drag and drop the guest speakers you want to join the party.
4. To boot a guest speaker from the party, just drag and drop in back into the drawer or just turn it off.

Note: If the guest speaker is not set as a public speaker, you will see a message with an extra step before that guest speaker can join the party. The owner of that speaker will need to press the Bluetooth button twice on their speaker.

The following speakers can join the party:

- ULTIMATE EARS Boom 3
- ULTIMATE EARS BOOM 2
- ULTIMATE EARS BOOM
- ULTIMATE EARS MEGABOOM 3
- ULTIMATE EARS MEGABOOM
- HYPERBOOM

Volume Control

When your speakers first enter the party, the volume of each guest speaker will sync up to the volume of the host speaker. If the volume of the host speaker is adjusted, the volume of all host speakers will also be adjusted. The volume of each guest speaker can also be adjusted individually. If you want the volume of all speakers in the party to sync up again, you can tap the volume sync icon in the PartyUp screen of the app.

Public Settings

The privacy setting in the PartyUp Settings allows you to control your speaker's promiscuity. If you want your speaker to be able to join any party, make sure the setting is ON. If you'd rather your speaker has more discretion, turn the setting off. But don't worry, if you prefer privacy, and still want to join a party, just double tap the bluetooth button once the host asks your speaker to join the party.

- Trouble logging to Amazon

Amazon login skipped during setup?

This can happen for a couple of reasons:

- You've already signed into the Amazon shopping app on your mobile device.
- You've already accepted Alexa's terms and conditions for your speaker (if you've set up your speaker already and have reset it or are setting it up again)

If this happens, sign out of your Amazon app then follow the steps below to sign into your account from the Ultimate Ears app.

1. In the Ultimate Ears app, in the top right, tap the Gear icon to go to speaker settings.
2. Find the Amazon Alexa section and tap it to sign into your account.
3. Tap Sign In to add your Amazon account.

WARRANTY –BOOM 3

[2 year limited hardware warranty](#)

At Logitech, it is our goal to ensure you are completely satisfied with your Logitech purchase. We take pride in the products and services we offer, and want our customers to enjoy them just as much as we do. If you are experiencing an issue, please click on the following link to learn more about the Logitech warranty.

help.ultimateears.com/ue-speakers-general/warranty

CONTACT US

We're here to help.

Please provide as much information as possible, so that our team can best assist you.

Our agents are here to help **Monday –Friday from 7 AM – 5 PM PST.**

help.ultimateears.com/contact-ue-support