



# **Installation Instructions**

## **Complete Set Rear View Camera**

v1.0 (20.10.2022)

## Contents

1	Liability Exclusion	3
2	Copyright	4
3	General notes	4
4	Safety Instructions	5
5	Requirements for the intended use	5
6	How to connect a cable to another	6
7	Note Cable Inscription/Color	7
8	Assembly Instructions	8
9	Assembly Note	9
10	Safety Instructions for working on Airbags	10
11	Disassembly tailgate covering	11
12	Disassembly back seat	12
13	Disassembly coverings rear passenger's side	13
14	Disassembly coverings front passenger's side	14
15	Disassembly main unit	15
16	Disassembly covering parts driver's side	16
17	Exchange tailgate emblem	18
18	Connection/Cable routing rear view camera/main unit	19
19	Connection/Cable routing fuse box/body control module (BCM)	20
20	Assembling the vehicle	21
21	Coding with Coding Interface	21
22	Coding Interface	21
23	Bus rest	22
24	Additional vehicle function	22
25	Connection/Troubleshooting cable set	22

## 8 Assembly Instructions

The following illustration shows the cable routing as well as the position of the individual components.




Figure 3: Vehicle overview

- 1 Rear view camera
- 2 Main unit
- 3 Fuse box, body control module (BCM)

Please be aware that this overview is only for **illustration purposes**. Always lay the cable set in the **most convenient and shortest way** possible. For a detailed description of the cable routing, please refer to the relevant sections of the following manual.