

VICSOON WAKE UP LIGHT

User Manual



Please read the instruction manual carefully before using the product and keep it with proper care.



5-year warranty & After-sales service

Please scan the QR code to enter our brand official website to get a 5-year warranty.



Phone: +1 8774031898

E-mail: vicsoonce@hotmail.com




If the product has functional defects, quality problems, missing parts or other problems. Please feel free to contact us, our customer service team will respond within 24 hours.

Customer Service Team Provides 24-hour Service




1. Specifications


Product name: Wake Up Light
Adapter input: 100-240V~50/60Hz 0.2A
Adapter output: 5V 1A
Wake up light input: DC5V 1A
Lighting power: 3W
Operating temperature: -10°C—50°C
Product net weight:288g
Product size: Φ106X151mm




2. Screen Presentation



3. Button Introduction



Smart touch key: Control light, alarm clock off
Long press to switch the warm white or colorful light mode
Short tap to adjust the brightness of warm light, or choose the colorful light you need, on/off lamp.



4. Clock Setting

- 1) Short press the clock setting button "⌚" to activate clock setting.
 - 2) Press "+" and "-" keys to select 12H or 24H. Confirm the setting by short press the key "⌚".
 - 3) Press "+" and "-" keys to choose the hours setting. Confirm the hour by short press the key "⌚".
 - 4) press "+" and "-" keys to set the minutes setting. Confirm the minute by short press the key "⌚".
- Note that please match the corresponding"AM"and"PM"time period in 12H mode

5. Alarm Setting

- 1) Hold down the alarm clock key "⌚" to activate the alarm clock settings, the hours or minutes symbol will flash in the display.
- 2) Adjust alarm time with use of "+" and "-" keys, then press the key "⌚" to confirm.
- 3) After setting the alarm time, it enters the selection for 7 options wake-up modes. Click the "+"and "-" button to select the favorite options, then press "⌚" to complete the setting.

Options 1-5 for the alarm ring and sunrise simulation wake up light.
Option 6 only with alarm ring and no sunrise simulation wake-up light.
Option 7 only with sunrise simulation wake-up light and no alarm ring.

- 4) When the alarm icon "⌚" is appeared on the screen and the alarm setting is completed and ready. IF you want to turn off the alarm clock, please press the alarm clock key "⌚".

Tip: Alarm clock volume setting: Click the "+"or "-" key to adjust the volume of the alarm ringtone under normal conditions.

6. Wake up & Snooze Mode Introduction

Enjoy the morning waking up in "sunrise" and nature sound with options 1-5 alarm mode. The light will automatically turn on 30 minutes before the alarm goes off, gradually increasing in brightness until the alarm goes off and the nature sound starts playing. Just tap the top touch button to turn off the alarm.

Note that if it is not turned off by hand during the alarm, it will be entered into the snooze mode and rings every 5 minutes.

7. Sleep Mode Introduction

Click the timer sleep button "T" to activate the sleep light mode, and the sleep light icon "Zz" will light up on the display. The sleep light has three timer options: 10/30/60 minutes timer. After the sleep light is turned on, the light will gradually dim to help you fall asleep.

8. Lighting Modes Introduction

When the machine connects to the power, you will have the option for the 3-level lights with low/middle/high brightness and turn off with only a touch of your finger on the top metal panel.

Long press the top panel to convert between the warm light and the colorful light mode.

In the colorful light mode, short press to switch the color of the lantern and the streamer gradient color. Lastly, tap the touch button to turn off the light.

9. Safely Instructions

- 1) The product has no battery, so it needs to be plugged in.Before connecting this product to the power supply, please check whether the voltage marked by the power adapter matches the local supply voltage.
- 2) Never use an adapter that exceeds the voltage and power marked on this product to connect the machine.
- 3) If an abnormal situation occurs during use, stop using it immediately and switch off the power.
- 4) Do not allow this product to enter into the water, do not use it in a humid environment (for example: bathroom, pool...) .
- 5) Please do not throw or hit this product to avoid damage to the product.
- 6) Recommended to use this product within the ambient temperature range:-10°C-50°C.
- 7) When not using for a long time, please turn off the power.
- 8) Under the condition of correct operation and compliance with the requirements of this manual, our company will provide users with repair or replacement services in case of product failure due to the functional fault during the warranty period.



Made in China

