# RUSTIC CONSOLE TABLE WITH DRAWER

3000018 - Instruction Manual





## **CONTENTS**

Safety Instructions	1
Hardware	2
Components	3
Assembly (Step 1 & 2)	4
Assembly (Step 3 & 4 & 5)	5
Assembly (Step 6 & 7)	6
Assembly (Step 8 & 9 )	, F 7
Assembly (Step 10 & 11)	8
Assembly (Step 12 & 13 )	9
Assembly (Step 14)	10
Cleaning & Warranty	11





#### PLEASE READ THESE INSTRUCTIONS CAREFULLY AND KEEP FOR FUTURE REFERENCE

#### IMPORTANT SAFETY INSTRUCTIONS

Do not use the Rustic Console Table with Drawer for any purpose other than that for which it is designed.

This product is not a toy. Children should be supervised to ensure they do not play with the product.

**CAUTION:** The assembly pack contains small parts which pose a choking hazard to children and pets. Keep children and pets clear at all times during assembly.

Locate the Rustic Console Table with Drawer in a suitable area where it will not be an obstruction. Place on solid, even ground.

This Rustic Console Table with Drawer is water resistant but not waterproof any prolonged contact with water can cause the wood to warp or damage the finish.

**CAUTION:** Do not place hot drinks directly onto the furniture.

WARNING! Never stand on, or rest on the product as this can cause damage or injury.

Do not overload the product as this may result in damage to the product or personal injury.

Do not exceed maximum weight capacity of 10kg.

Do not clean the product with any abrasive chemicals, solvents and detergents as this can damage the surface.

Periodically check the fittings and secure as necessary (every 3 months or as required). Re-tighten the fittings 1 week after first assembly.

Take care not to over tighten any fixings as this could damage the product.

Always assemble near to the area to be installed/placed.

Ensure you have sufficient space to assemble the product.

**CAUTION:** Do not use any power tools to assemble the product as this could cause damage to fixings and panels.

#### **Anti-Tip Safety Strap Information**


It is recommended that furniture items above 75cm in height should be secured to a wall to prevent accidental tipping.

#### Securing the Anti-Tip Strap (Not Supplied)


- 1. Attach the Anti-Tip Strap to the back of the unit secure into place
- 2. Place the unit against the wall you wish to be located and mark the wall where the tip strap will be attached.

**NOTE:** it is recommended to attach the tip strap a little lower than the top and depending on location (centre or either side)


3. Use the appropriate wall fitting to secure into place.



### **HARDWARE**




## **COMPONENTS**




www.VonHaus.com


#### STEP 1




#### STEP 2




#### STEP 3




#### STEP 4




#### STEP 5




STEP 6




#### STEP 7




#### STEP 8




#### STEP 9




#### **STEP 10**




#### **STEP 11**



**STEP 12** 




**STEP 13** 



#### **STEP 14**



Please Purchase correct wall plug fitting for your wall



10 www.VonHaus.com

### **CLEANING**

A weekly dust will help shift the filmy layer of airborne deposits that build up over time and can scratch the surface of your furniture.

Dampen a clean, dry cloth (non-scratching and preferably microfibre) with water and gently wipe the surface.

The moisture will collect the dust and prevent any flyaway dust particles.

**CAUTION:** Avoid using any abrasive cleaning solvents on the (Rustic Console Table with Drawer) as this may damage the surface.

### **CUSTOMER SERVICE**

If you are having difficulty using your product and require support, please contact hello@domu.co.uk

### **DISPOSAL INFORMATION**

Please recycle where facilities exist. Check with your local authority for recycling advice.

#### **WARRANTY**

To register your product and find out if you qualify for a free extended warranty please go to

#### www.Vonhaus.com/warranty.

Please retain a proof of purchase receipt or statement as proof of the purchase date.

The warranty only applies if the product is used solely in the manner indicated in the Warnings page of this manual, and all other instructions have been followed accurately. Any abuse of the product or the manner in which it is used will invalidate the warranty.

Returned goods will not be accepted unless repackaged in its original packaging and accompanied by a relevant and completed returns form. This does not affect your statutory rights.

No rights are given under this warranty to a person acquiring the appliance second-hand or for commercial or communal use.

### COPYRIGHT

All material in this instruction manual are copyrighted by DOMU Brands.

Any unauthorised use may violate worldwide copyright, trademark, and other laws.



### Thank you for purchasing the Rustic Console Table with Drawer

VonHaus® is a registered trademark of DOMU Brands Ltd Made in China for DOMU Brands Ltd M24 2RW

