BroadLink











Having issues of using the product? Please contact us before returning.

xupport@ibroadlink.com

We are always be ready to help until you smile :)

- For wall-mounting use, ONLY stick the back cover to flat
- surface to avoid dropping.

 If the battery is low, button 1 will flash once when any button is pressed. You should change the battery asap.

 The use of App doesn't require
- creation of account for simplest experience. We still highly recommend users to create account so when you change a phone and log in with same account, everything will be automatically synced without setting up again.
- Why we need to long press the button combination to save changes?
- For battery saving, the scene switch is "sleeping" most of time and will be triggered to wake up only when it is pressed for communication - this is a common design for battery powered sensors.
- FCC ID: 2ATEV-SC4B4
 This device complies with Part 15 of the FCC Rules. Operation is subject to the following two
- conditions:

 This device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation.



User Manual


Scene Switch | SC4B4



www.ibroadlink.com Email: support@broadlink.com


320mm

Overview



72mm

72mm



Front







Back

Product Features

Press and Hold ≥2s

You can simply press and hold

the lights in the room, or press

tune the color temperature to

warm white / cool white. • NOTE: The quick dimming / color change operations are only effective for lights which are already turned on.

button 1/2 (≥2s) to dim/brighten

and hold the button 3/4 (≥2s) to













Quick Dimming



■ What's Required









- iOS 11.0 / Android 5.1 or higher with Bluetooth turned on. FastCon BLE enabled lights.
- Open the cover and remove battery insulator for first use to power the device.

STEP 1 Install APP



- Scan the QR code or search "BroadLink BLE" in App Store or Google Play to download and
- install the free App.

 Account creation is not mandatory to use the App. However, as an option, you can go to "Me" tab to create your account for syncing data between different mobile

STEP 2 Add Device



- Tap "Add Device" > "Scene Switch" > "Add Devices" to let the App scan devices to be paired.
- Press and hold buttons 1&4 or 2&3 for 4s to reset the device until all LEDs are flashing. Then wait for the device to be discovered automatically in the App. You can rename the device and tap "Done" to complete pairing.

STEP 3 Use Preset **Scenes**



- The scene switch is ready-to-use after pairing. The 4 buttons match the first 4 scenes preset in the room which the switch is assigned.
- Now you can just press and activate the scenes from the buttons.

Step 4 Change Scene Setting



- You can tap the ":" to edit the scene (ex. Change another button to activate the scene or associate
- a new scene to a button).

 Tap "+ Add Trigger" and choose scene switch and button.
 • Then tap "Save" and wake up the
- device again with long pressing the button combinations to save the change.

正面