



Can't connect to Wi-Fi 6 products wirelessly?

Some older versions of driver or software for wireless devices may be incompatible with Wi-Fi 6 products.

If you are experiencing problems connecting to your Wi-Fi 6 products, please update the driver or software for your wireless devices.

How to update driver?

1. Check the model for your wireless adapter.
2. Go to the manufacturer's website for latest driver version.
3. Update the driver. You can contact them for further assistance in updating.

For more detailed instructions, refer to <https://www.tp-link.com/faq-2303.html>