

尺寸： 85*195

彩色印刷 128g 铜版纸



Sleepless or Restless? Soothing the Little One with Gianna Lullume.

(User Manual)



Get Started

1.Plug it in
Connect the power cable to the Gianna Lullume device, then plug it into your power outlet.

2.Download the App
① You can directly access our App by scanning the QR code here.



② Download the app. Down load the 【K-life】 app to your phone or tablet from the Apple App or Google Play store.



③ Connect your 【K-life】 & Follow the steps in the app to connect your Gianna Lullume.



1

3.Network Setup Instructions

Press and hold for 5 seconds to pair the device or reset the network. You will hear a prompt sound, and the blue light will flash to indicate the action.



4.Wi-Fi Connection Instructions
Only 2.4GHz Wi-Fi networks are supported for app configuration.



2

Get to Explore Your Gianna Lullume



① **Power Control:**
① Upon connecting to power, the device will automatically turn on, regardless of its status.
② When disconnected from power, press and hold for 2 seconds to turn on/off.

② **Dimmable Clock Control:**
Short press to adjust the clock screen brightness.

③ **My Favorites:**
Tap to access or toggle between app-saved sound and light modes; hold for 2 seconds to turn off.

④ **Nightlight Control:**
Short press to turn the light. on/switch light modes; long press for 2 seconds to turn off the light.

⑤ **Network Configuration:**
Press and hold for 5 seconds to pair the device or reset the network. You will hear a prompt sound, and the blue light will flash to indicate the action.



3

⑥ **Brightness Control:**
turn right to brighten, left to dim.

⑦ **Volume Control:**
turn right to increase, left to decrease volume.

⑧ **Charging Port :**
Connect your device here.

⑨ **Child Lock Light:**
The child lock button light turns on when activated.

⑩ **Battery Light:**
When battery is below 20%, the red light flashes.

⑪ **Network Light:**
The blue light flashes during network pairing.



⑫ **Clock Display:**
Displays the local time.

⑬ **Wake-up icon:**
This icon lights up when the function is turned on.

⑭ **Sleep setting icon:**
This icon lights up when the function is turned on.

Factory Reset:

Hold Music ③ + Night Light ④ buttons for 3 seconds until the screen shows 00:00.

Note:
This erases all settings.
Use for reconfiguration or troubleshooting.
Reconfigure the device after reset.

Ps: During wake-up or sleep reminders, if the child lock is not activated, pressing any button will turn off the reminder function.

4

App Remote Control



① **Power Control**
Remote control to turn the device on or off.

② **Child Lock**
Prevents accidental changes to settings by children.

③ **Favorites List**
Saves preferred settings or modes for quick access. Supports 8 customizable smart sleep soothing modes: music and light combinations.

④ **Routine**
The new Routine feature lets you customize daily schedules for nap time, reading, and more. Create the perfect environment for your baby's needs while fostering healthy habits. Parenting has never been this easy.

5

⑤ **Smart Soothing**
Tap the "Smart Soothing" Control to activate. The system will begin soothing the baby, and If the baby continues crying after 60 seconds, the app will alert parents via message notification.

⑥ **Wake-Up Setting**
Tap the "Wake-Up Setting" Control to activate the function. The app will gradually increase light or sound at the set time.

⑦ **Sleep Setting**
Tap "Sleep Settings" to customize the light, sound, and other preferences to support the baby's sleep training.

⑧ **Light Color Control**
Select the light color option from the app and choose your preferred color from the palette.

⑨ **Auto-Off Timer**
Sets a timer to automatically turn off the soothing music and light after a set duration.

⑩ **Sound Control**
Tap "Sound Control," then choose from 34 available soothing tracks.

⑪ **Volume Control (0% to 100%)**
Adjusts the volume level of sound or music.

⑫ **Brightness Control (0% to 100%)**
Adjusts the brightness of the light to increase or decrease the brightness.

⑬ **Device Selection**
Tap "Device Selection" to view and select the device you wish to control if more than one device.

⑭ **Setting**
Tap " Settings" to adjust the language, display settings, restore to factory defaults, delete the device, view FAQs, or download the user manual.

⑮ **Power Status Display**
Shows the current battery or power level of the device. Turns yellow below 20% and red below 10%. Please recharge promptly to ensure proper operation.

6

Safety Instructions

- Read all instructions before use and keep out of reach of children (recommended for users over 16 years old).
- Do not expose the product to fire, high temperatures, moisture, or disassemble without permission.
- When disconnecting the power supply,pull the plug first.Do not pull the cord by itself.Never handle the power plug with wet hands,as this could cause fire or electric shock.
- Do not twist or pinch the power supply cord.If the plug or power supply cord needs to be replaced,ensure that it complies with the manufacturer's recommendation.
- Keep the product clean, dry, and free from oil; clean with a dry cloth.
- Custom features require a connection to the app to function. Ensure the app and product stay linked for optimal performance.

Need Assistance?

Gianna support makes your peace come true. Reach out to us at support@giannashop.com Follow @giannashop to explore the magic of peace.

 @giannashop.official

 @Giannafamily

 @Giannashop

 @Giannashop

 @giannashop

WWW.GIANNASHOP.COM

7

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.