ID Diagram **Wireless Microphone** (1) Windproof Net User Manual (2) Connection/mute indicator light (3) Noise reduction/ :00 reverberation indicator light Power indicator light (5) Microphone Type-c charging port (6) Magnetic clamp (7) Power button (8) Port to connect phone Charging interface (ii) Indicator light CEFC & X & ® Q 11) Charging box Type-C charging port (12) Charging box indicator

How to use Step 1: Long press the power button on the microphone, and the connection indicator light will flash, indicating successful power on.

Step 2: Connect one end of the receiving end to the phone interface. Step 3: The indicator light for the connection between the receiver and transmitter remains on, indicating a successful connection. Open the camera live streaming app on your phone and use the



Note: oppo / vivo / igoo / realm brand mobile phones can be

used normally only when they go to the settings

(search "OTG" - turn on OTG power supply)

Microphone Transmitter Function Button LED Automatically power on and pairs when Power on taken out of the charging case

About UI

Power off ong press the 3S power butto All lights are off oise reduction on: The noise reduction blue light is always on Noise reduction Click the power button loise reduction off. The noise reduction light is off Mute on: The mute light is on Silent mode Double click the power buttor Mute off: Mute light off Noise reduction mode furned on reverb: noise reduction blue light and reverb green light are on Three click the power button Original sound mode turned on reverb: reverb green light is Turn off reverberation: The reverberation green light goes out When charging, the power indicator light is always Charging red and on, and when fully charged, the light is off The battery level is below 20%, Low electricity

and the red light flashes slowly

connection indicator light flashing slowly

Not connected Connect 1 microphone Connect 2 microphones

Receiver

Volume switching

Function

Press the three buttons to enter stays on, TX2 flashes rapidly Enter pairing mode

Click the button to increase o

decrease the volume in three

LED

TX1 and TX2 indicator lights flash

TX1 stays on, TX2 stays on for

TX1 and TX2 indicator lights are

One level volume: Volume 1 light is

lights are always on, and volume 3 is off

Three levels of volume: volume, all three lights are constantly on

Unconnected triple tap: TX1 and TX2

Connect only TX1 for three clicks: TX1

Connect only TX2 three strikes: TX2 stays on, TX1 flashes rapidly:

After TX1 and TX2 are connected: Three press button operation is invalid

15 seconds before turning off

always on, 2 and 3 are off.

lights flash simultaneously

(4) Charging cable

(5) User manual

Packing List

Content of packing

(3) Charging box

(2) Lightning receiver

(1) Microphone transmitter