

QUICK START GUIDE®

Please read these instructions completely before operating this product.

805008808

Important!

Do not touch screen.



To download your copy of the complete Owner's Manual:

<http://consumersservicerefurbish.com>


Click on: Download Owners Manual
On Manufacturer or Brand, select: VIZIO
On Product Type, select: TV
On Model Number, select: M50Q7-J01 / M55Q7-J01 / M58Q7-J01 / M65Q7-J01 / M70Q7-J03 / M75Q7-J03.

What's Inside the Box


Smart TV | Power Cable | Voice Remote | TV Feet with Screws

1 Stand Setup

Place TV on a padded, flat surface that is larger than the TV, before installing feet or wallmount (not included).




These arrows should be facing down/towards the screen.



Use top two holes: taller TV height.
to use w/sound bar
(doesn't block screen when in front)


OR



Use bottom two holes:
shorter TV height

Note: The image shown here is for illustrative purposes only and may be subject to change.
The actual number of ports and their locations may vary depending on the model.

3 Remote Control



(Batteries not included).

Accessibility Features

CC

Press the **CC** button to enable/disable **closed captions**.
Hold down for 5 seconds to access the Accessibility Menu with features like **Talk Back** and **Zoom Mode**.



The remote control may vary depending on the model: The buttons on remote control may have a different name or location than the remote control shown in this manual.

2 Connect



Why should I use HDMI?

Highest Quality Connection:
Connect your devices with HDMI for the best possible picture and sound.



HDMI

Dedicated Sound Bar Connection:
Connect a sound bar to the HDMI 1 (eARC) port on the TV (marked in green).



HDMI 1 (eARC)

4 Complete On-screen Instructions



Want the best viewing experience?

Select a **Picture Mode** setting that best fits your room & lighting.

Note: The image shown here is for illustrative purposes only and may be subject to change.
The actual number of ports and their locations may vary depending on the model.

The cables mentioned in this manual are not supplied with your unit.

