

Installing the Litter-Robot 4 Carbon Filter

Litter-Robot 4 is equipped with a flexible carbon filter pad that is installed on the outer bottom area of the globe. This filter sits directly over the waste drawer to absorb odors. (The carbon filter is not required for the unit to function.)




How to install




- ✓ Press and hold the Cycle  and Empty  buttons on the control panel **for 3 seconds**, or tap "Replace Filter" under Controls in the app.



- ✓ A clean cycle will begin; the cycle will pause when the globe reaches the "replace filter" position.



- ✓ Open the bonnet: Press and hold the latches on both sides of the bonnet, then lift and rotate the bonnet to its open position to reveal the filter pocket.



- ✓ Open the filter cover and replace the carbon filter as needed. (Under normal use, 1 filter should last approximately 1 month.)



- ✓ Close the bonnet: Rotate the bonnet downward over the globe and push down on the bonnet from the top to make sure it is latched and secure.



- ✓ Press the Cycle  or Reset  button to resume the clean cycle; when the clean cycle has ended, press the Reset button to zero the weight sensors.