






Original	Recharge	Original	Recharge
	Power		Power
	Mute		Mute / Dimmer
	Ni cam / A2		Shift + Audio / Lang I / II
	Aspect		Shift + Picture / Format
	P. Mbde		Picture / Format
	S. Mbde		Sound / Title
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	- / - -		Shift + Guide / EPG / - / - -
	0		0
	Recall		Back / Return
	Display		Display / Media
	Freeze		Pause / Step / Freeze
	Rec / Auto		Rec / Rec Mode
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Sleep		Sleep / Timer
	Up		Up
	Source		AV / Input / RDS
	Left		Left
	Enter		OK
	Right		Right
	Down		Down
	Menu		Menu / Home
	Exit		Exit / Cancel / Clear



