

⚠ Important Notes

- Turn off the device (①) after use. It will **NOT** turn off automatically.
- Do **NOT** open the device. Opening causes permanent damage and voids the warranty.
- Change coin battery when low battery icon shows on indicator display to avoid false readings.

Description

- ① **Zero/On Button** – Short press when dial is off - turn on dial indicator
– Short press when dial is on - zero dial reading
– Long press when dial is on - turn off dial indicator
- ② **ABS/Preset Button** – Short press - switch dial indicator between absolute measurement mode and relative measurement mode
– Long press - set preset value
- ③ **Unit Button** – select reading in inch/mm
- ④ **Status LED**
 - – Blue LED Flashing – Bluetooth transmitter on, waiting to be connected
 - – Blue LED Solid – Bluetooth transmitter connected
 - – Blue LED off – Bluetooth transmitter off
- ⑤ **Dial Battery** – insert CR2032 battery



Included in the box

- BlueDial Flat 1X
- CR2032 Battery 1X
- User Guide 1X

Compatible Software

- iOS: MultiGage Reader (download for FREE from the App Store)
- Android: MultiGage Reader (download for FREE from the Play Store)



MultiGage Reader App
iPhone/iPad

MultiGage Reader APP
Android



Quick Start

- Insert CR2032 coin battery into dial indicator if it's a first-time use.
- Short press Zero/ON button to turn on BlueDial Flat.
- Make sure blue LED is flashing.
- Run one of the apps, then tap + button to enter pairing page.
- Wait for the software to finish scanning nearby devices, then select **BlueDialFTxxxx** to connect.
- Once paired, BlueDial Flat readings show in the software.
- To turn off BlueDial Flat, long press the Zero/ON button.
- Bluetooth transmitter goes to sleep after 3 minutes if there is no connection.
To wake up the Bluetooth transmitter, turn BlueDial Flat off for at least 5 seconds and then turn it back on.