



SAFETY INFORMATION

Released Date: 2022-01-17

Please read and understand this entire manual before attempting to assemble, install or operate the product.


WARNING

- RISK OF ELECTRIC SHOCK - Before beginning installation, turn off electricity at the circuit breaker box or the main fuse box.
- RISK OF FIRE - Use bulbs specified by the markings and/or labels on the fixture.

CAUTION

- For your safety, read instructions completely before beginning installation.
- If in doubt about electrical installation, consult a licensed electrician.
- Turn off electricity to fixture before replacing the bulb(s).

TOOLS REQUIRED




CARE AND MAINTENANCE

- Wipe clean using soft, dry cloth or static duster. Always avoid using harsh chemicals and abrasives to clean fixture as they may damage the finish.

If you need further assistance call Quoizel Customer Care at 1-800-645-3184(9:00am - 5:00pm EST), or visit us on-line at www.quoizel.com


PACKAGE CONTENTS



A Fixture Body
X 1




B Socket Collar
[Pre-assembled to
Fixture Body]
X 1



C Glass Shade
X 1

MOUNTING HARDWARE




AA Crossbar Assembly
X 1



BB Wire Connector
X 3




CC Outlet Box Screw
X 2



DD Quick Link
X 2




EE Fixture Chain
X 1



FF Ceiling Canopy
X 1

INSTALLATION

1 Install Crossbar Assembly




2 Install Fixture Chain




OPTIONAL: Adjust Chain as desired, using pliers and soft cloth (neither included).

Suggested chain length for Ceiling height:
8 feet ceiling: use 12 links of chain and 2 quick links
9 feet ceiling: use 22 links of chain and 2 quick links
10 feet ceiling: use 32 links of chain and 2 quick links.




3 Pull Supply Wires

Pull the supply wires with ground wire through the chain alternate links.




4 Wiring




5 Install Ceiling Canopy

* Ceiling Canopy shape is varies depends on item purchased.



6 Install Glass Shade and Bulb



Install the correct bulb referring to fixture markings and/or labels for maximum wattage.

Recommended Bulb Type (not included):



BULB BASE TYPE
Medium (E26)



BULB TYPE
TYPE A

Your installation is now complete! Restore electricity and save this sheet for future reference.