



L1 Pro Family

Firmware Update

English


These instructions explain how to update the firmware of your L1 Pro8, L1 Pro16, L1 Pro32, Sub1, or Sub2.

Note: A USB-C cable is required (not included with your product). The L1 Pro family of products is not compatible with Thunderbolt 3 cables.

1. On a computer, open a web browser and go to **btu.bose.com**.
Note: Not compatible with Internet Explorer or Safari.
2. Click **Download** to download the **Bose Updater**.


Compatible Web Browsers	
Windows	Google Chrome, Mozilla Firefox, Microsoft Edge
Mac	Google Chrome, Mozilla Firefox

Bose Updater



3. View the End-User License Agreement, then click **I Agree**.
4. Install the **Updater**.


Bose Updater



5. Once installed, open the **Updater**.
6. Plug your product into a power source.
7. Connect your product to your computer using a USB-C cable. The **Updater** will identify your product automatically.

8. If your product needs a software update, your screen will read, **There's an update available for your product!**

Bose Updater




9. Click **Update Now**.
Note: Do not unplug or power off your product while the update is in progress.

Bose Updater



10. Once the update is complete, your screen will read, **Your product is now up-to-date!**

Bose Updater





866459-0010

©2020 Bose Corporation, All rights reserved.
Framingham, MA 01701-9168 USA
www.Bose.com
AM866459 Rev. 00
September 2020

