


UX400 ARGB Sync









AMD Installation Guide







Fan & MB SYNC Installation Guide

Please power off the PC and check the Positive and Negative ends on the connector before connecting the cable to mainboard. **CAUTION** Connecting the wrong end can damage the fans.

