

Truebuds

MANUFACTURER

Shenzhen SoundSOUL Information Technology Company Limited

Room 1308-1309, Building 8, Huihai Square, Chuangye Road,  
Longhua District, Shenzhen, China. 518109

support@soundpeatsaudio.com

www.soundpeatsaudio.com

FC

RoHS

CE

PS

日本電産株式会社

211-10629

MADE IN CHINA

FCC ID: 2AFUCC004

Truebuds

SOUNDPEATS

USER MANUAL | Manuel d'utilisation | Bedienungsanleitung |  
Manual de Instrucciones | Manuale di istruzioni | 取扱説明書 | 说明书

Package Content

Specifications

Bluetooth Version	5.0
Bluetooth Chipset	RTL8763BP
Maximum Working Range	10m (without obstacle)
Talk Time	About 3.5 hours
Earbud Charging Time	About 1.5 hours
Case Charging Time	About 3 hours
Charging Case Recharge Earbuds	20 times
Earbud Dimension (L * W * H)	43.5*21.7*17mm (earbud)

Product Diagram

Controls

Power On	Automatically: Take out the earbuds from charging case Manually: Long press the multifunction button for 1.5s when the headset is off
Power Off	Automatically: Place the earphones back into the charging case Manually: With the headset on, long press the Multifunction button for 10s
Play / Pause	Double click the multifunction button of any earbuds
Volume +	Click the right multifunctional touch button once
Volume -	Click the left multifunctional touch button once
Previous Track	Long press the left multifunction button for 1.5s
Next Track	Long press the right multifunction button for 1.5s
Answer / Hang Up Phone Call	Double click the multifunction button of any earbuds
Reject Phone Call	Long press the multifunction button of any earbuds for 1.5s
Switch Between Two Active Calls	Long press the multifunction button of any earbuds for 2s
Activate Voice Assistant	Click the multifunction button of any earbuds three times

Wearing the Earphones

Getting Started

Pairing and Re-Pairing

1.Pick up the left and right earbuds at the same time from the charging case when the charging case is powered, both earbuds will enter TWS Pairing mode automatically. You will hear a voice prompt when the left and right earbuds connect to each other successfully. Then the white indicator of left earbud will light on, and the right indicator starts alternately flashes in red and white with a voice prompt "pairing" indicating pairing mode.  
2."SOUNDPEATS Truebuds" will show up on the Bluetooth list, click it to connect. You will hear a voice prompt "connected" from right earbud when the earbuds connect with your device successfully.

3.SOUNDPEATS Truebuds Bluetooth earbuds can remember previously paired devices. When you make the second connection, simply activate the Bluetooth in your device, take out the both earbuds from the charging case. They will connect to each other, and reconnect to your device automatically. If the earbud doesn't automatically connect to your device, please activate the Bluetooth in your device and hit "SOUNDPEATS Truebuds" on the Bluetooth list.

Note:

1. If the left and right earphones didn't pair with each other within 5 seconds. When taking out a single earbud, the earbud will enter the pairing mode and can be used individually.  
2. If you want to change the pairing device in the connected state, please turn off both earbuds, then press and hold the multifunction button of the right earbud for 6s to have it enter pairing mode directly and pair to a new device.

Factory Reset

(Try the following steps if you fail building connection between two earbuds, or between earphones and device)  
1.Clear pairing record between the earbuds and all your devices.  
2.Place back both earbuds into the charging case and ensure they're in charging status. Then long press the multifunction button of both earbuds for 10s until the LED light of both earbuds flash white twice.

Charging

SOUNDPEATS Truebuds Bluetooth earphones are equipped with a lightweight charging case which is not only a charging dock to charge the earphones, but also a carrying case. With a built-in rechargeable battery, the charging case can provide up to 20 times full charge for the earphones (both left and right).

Charging the headset

The earphones are partially charged at the factory. Please make sure they are fully charged before first use.  
1.Put the earphones into corresponding charging docks, make sure the charging contacts are match.  
2.The LED indicator will turn red when it starts charging.  
3.The red LED indicator will turn off when the earphones are fully charged.

Charge the case

When charging case battery is low, the last indicator of the charging case will flash white. Please charge the case soon.  
1.Connect the charging port with Type-C charging adapter. (Please make sure the current is not greater than 1A)  
2.Please charge the case at least once every 3 months when not in use for a long time.

Charging other devices

When your phone and other devices have low power, connect the charging case through the phone charging cable to emergency charge your phone and other devices. (Charging case stable output 5V / 1A)

Warranty

We warrant this device 12 MONTHS from date of the original purchase for manufacturer defects.  
If the device fails due to a manufacturing defect, please contact seller directly to initiate return and warranty process.  
support@soundpeatsaudio.com  
www.soundpeatsaudio.com  
Please scan the QR code to check the detailed PDF manual.

https://soundpeatsaudio.com/downloads/

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-- Reorient or relocate the receiving antenna.  
-- Increase the separation between the equipment and receiver.  
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-- Consult the dealer or an experienced radio/TV technician for help.  
  
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.  
  
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.