



IOC-224

denver.eu

01/2025



Points de collecte sur www.quefairede mesdechets.fr
Privilégiez la réparation ou le don de votre appareil !

Safety information

Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.

1.This product is not a toy. Keep it out of reach of children.

2.Keep product out of the reach of children and pets to avoid chewing and swallowing.

3.Product operating and storage temperature is from -20 degree Celsius to 60 degree Celsius. Under and over this temperature might affect the function.

4.Never open the product. Touching the inside electrics can cause electric shock. Repairs or service should only be performed by qualified personnel.

5.Only charge with the original adapter supplied with this product!



6.Only use with the attached accessories. Using non original accessories can make the product work abnormal.

Quick Start Guide

- Prepare your Wi-Fi network and password.
- Make sure your mobile device is running iOS 8 or higher or Android 10.0 or higher.
- Make sure a 2.4 GHz Wi-Fi network is used. A 5 GHz network is not supported.
- Download and install the Tuya Smart app from App Store or Google Play.



Open the app, and it will ask you to register your device. Select your country, enter your email, get a verification code, and input your chosen password to confirm.



For new users, please select “Agree” in the tips pop-up.

1) Allow Tuya Smart to access mobile cellular data and wireless LAN; otherwise, you cannot add a camera.


2) Enable the push notification function on Tuya Smart; otherwise, the phone will not receive alarm push notifications.

3) Allow Tuya Smart to use the microphone when you want to use a 2-way audio function.

Adding a smart Wi-Fi camera:


Power on: Camera power cable connect with an adapter and adapter plug in the socket. The camera will automatically rotate horizontally and vertically, and then you will hear a beep.

· Open the “Tuya Smart Home” app, tap “+,” and then tap “Add Device.” Choose “Camera & Lock” and then tap “Smart Camera (Wi-Fi)” to add a new smart Wi-Fi camera to your app.




· When a prompt tone is heard, tap "Next".

Reset the device




Power on the device and make sure the indicator is flashing rapidly or a prompt tone is heard.

-  Make sure the indicator is flashing quickly or a prompt tone is heard

Next

[Reset Device Step by Step](#)


•Select the same connected Wi-Fi network of your phone or tablet and input the Wi-Fi password, then tap “Confirm.”




20:30 



✕



Select 2.4 GHz Wi-Fi Network and enter password.

If your Wi-Fi is 5GHz, please set it to be 2.4GHz.
[Common router setting method](#)

 Wi-Fi - 5Ghz



 Wi-Fi - 2.4Ghz  

 ChinaNet-6uhk 



 5ks6tatm 

Next

•Tap “Continue,” and the mobile phone will display a QR code. Use the camera to scan the QR code 15 cm to 20 cm away from the mobile phone.



Tap "I Heard a Prompt" when you hear a prompt sound. The smart Wi-Fi camera is trying to connect to the app. Once connected successfully, the app will show "Added successfully" and "Security Camera added successfully".



- Tap “Done” to view the live stream of your camera.

Detection Alarm Settings:

Tap on “Detection Alarm Settings ” where you can then turn on/off the motion detection alarm. Once turned on, any motions detected will leave a notification.

You can check notifications on the “Message” tab of the app. Motion alarm sensitivity level can be set as follows:

- Low Sensitivity – records any movements within 5 meters
- Medium Sensitivity – records any movements within 10 meters
- High Sensitivity – records any movements within 15 meters

Remove Device: Tap on “Remove Device” if you want to delete this camera.

Note: A Micro SD card (not included) will perform Event Recording or Non-Stop Recording. Upon reaching its maximum storage capacity, the card will automatically overwrite the oldest recording. This will erase the oldest recording and replace it with the new recording. For longer access to important recordings, it is recommended to move the recordings from the Micro SD card to your computer, etc. You can view recorded videos under the playback icon.

AC/DC ADAPTER

Manufacturer's name or trade mark, commercial registration number and address	Company name: Shenzhen Keyu Power Supply Technology Co., Ltd. Address: 2~3F, No. 13, Lane3, Yuquan East Road, the 2nd Industrial park, Yulv Guangming District, 518000 Shenzhen, China Commercial registration number: 91440300591889293H
Model identifier	BS05A-0501000EU
Input voltage	100-240V
Input AC frequency	50/60Hz
Output voltage	5.0V
Output current	1.0A
Output power	5.0W
Average active efficiency	73.86%
Efficiency at low load (10%)	72.92%
No-load power consumption	0.051W

Please notice - All products are subject to change without any notice.
We take reservations for errors and omissions in the manual.

ALL RIGHTS RESERVED, COPYRIGHT DENVER A/S



denver.eu



ENG7

Electric and electronic equipment contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment) is not handled correctly.

Electric and electronic equipment is marked with the crossed out trash can symbol, seen above. This symbol signifies that electric and electronic equipment should not be disposed of with other household waste, but should be disposed of separately.

All cities have established collection points, where electric and electronic equipment can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Denver A/S declares that the radio equipment type IOC-224 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: denver.eu and then click the search ICON on topline of website. Write model number: IOC-224. Now enter product page, and RED directive is found under downloads/other downloads.

Operating Frequency Range: 2.4~2.4835 GHz

Max Output Power: 5W

DENVER A/S

Omega 5A, Soeften

DK-8382 Hinnerup

Denmark

www.facebook.com/denver.eu

Contact

Main contact point: contact.hq@denver.eu

Nordics

Headquarter

Denver A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark

Phone: **+45 86 22 61 00**

(Push "1" for support)

E-Mail

For technical questions, please write to:
support.hq@denver.eu

For all other questions please write to:
contact.hq@denver.eu

Benelux

DENVER BENELUX B.V.

Barwoutswaarder 13C+D
3449 HE Woerden
The Netherlands

Phone: **0900-3437623**

E-Mail: **support.nl@denver.eu**

Spain/Portugal

DENVER SPAIN S.A

Ronda Augustes y Louis Lumiere, n° 23 – nave
16
Parque Tecnológico
46980 PATERNA
Valencia (Spain)

Spain

Phone: **+34 960 046 883**

Mail: **support.es@denver.eu**

Portugal:

Phone: **+35 1255 240 294**

E-Mail: **denver.service@satfiel.com**

Germany

Denver Germany GmbH Service

Max-Emanuel-Str. 4
94036 Passau

Phone: **+49 851 379 369 40**

E-Mail

support.de@denver.eu

Fairfixx GmbH

Repair and service
Rudolf-Diesel-Str. 3 TOR 2
53859 Niederkassel

(for TV, E-Mobility/Hoverboards/Balanceboards,
Smartphones & Tablets)

Phone: **+49 851 379 369 69**

E-Mail: **denver@fairfixx.de**

Austria

Lurf Premium Service GmbH
Deutschstrasse 1
1230 Wien

Phone: **+43 1 904 3085**

E-Mail: **denver@lurfservice.at**

Poland

LetMeRepair Poland sp. z o.o.

ul. Częstochowska 140
62-800 Kalisz

Phone: **62 75 38 092**

E-Mail: **denver-service@letmerepair.pl**

Godziny pracy: 8 – 18 (poniedziałek – piątek)

If your country is not listed above,
please write an email to
contact.hq@denver.eu



Denver A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark

denver.eu
facebook.com/denver.eu

