


1 TRUE WIRELESS
STEREO

Quick Guide

1

Bluetooth Pairing

Take out the two earbuds, they will automatically power on and connect each other within 10 seconds. One of the earbud flashes red and blue alternately (Pairing Mode). Search for pairing name [TOZO - A1].



Register your extended warranty

Scan within 14 days

Activate 18-Month Extended Warranty

Or visit " service-survey.vip/a1 "

2

Wearing

1. Ensure the eartip facing downwards, then place the earbuds into your ears.
 2. Rotate the earbuds back to the auricleside to fit snugly.
- *Eartip facing upwards is the incorrect way to wear the earbuds.



Select your fit



Insert



Twist to lock



Wrong demo



3

Smart touch control

EN | JP | DE | FR | IT | ES | NL | SE

X1: Press once **X2:** Press twice **X3:** Press three times **Hold:** Press and hold for 2 seconds

X2



Previous song | 前の曲 |

Vorheriges lied | Chanson Irécédente |
Canzone precedente | Canción anterior |
Vorig nummer | Föregående låt

Hold



Volume down | 音量を下げる |

Lautstärke runter | Baisser le volume |
Volume basso | Bajar volumen |
Volume verminderen | Sänk volymen

X1



Play/Pause | 再生/一時停止 |

Spielen/Pause | Jouer/Pause |
Giocare a/Pausa | Tocar/Pausa |
Toneelstuk/Pauze | Spela/Paus

Hold



Hang up | 電話を切る |

Auflegen | Raccrocher |
Appendere | Colgar |
Ophangen | Lägga på

X3



Activate the voice assistant | 音声アシスタントをアクティブにする |

Aktivieren Sie den Sprachassistenten | Activer l'assistant vocal | Attiva l'assistente vocale |
Activar el asistente de voz | Activeer de stemassistent | Aktivera röstassistenten

X2



Next song | 次の曲 |

Nächstes lied | Chanson prochaine |
Canzone prossima | Canción siguiente |
Volgende nummer | Nästa låt

Hold



Volume up | 音量を上げる |

Lauter | Monter le son |
Alza il volume | Sube el volumen |
Volume omhoog | Höj volymen

X1



Answer | 答え |

Antworten | Réponse |
Rispondere | Responder |
Antwoorden | Svar

Hold



Reject | 拒絶 |

Ablehnen | Rejeter |
Rifiutare | Rechazar |
Afwijzen | Avvisa



Power on

Power off

EN

Power on :

Take out the earbuds from the charging case;
or press and hold 5 seconds.

Power off :

Place the earbuds back into the charging case;
or press and hold 5 seconds.

DE

Ein :

Nehmen Sie die Ohrhörer aus dem Etui oder halten
Sie sie 5 Sekunden lang gedrückt.

Ausschalten :

Legen Sie die Ohrhörer wieder in das Etui oder
halten Sie sie 5 Sekunden lang gedrückt.

IT

Accensione :

Estrarre gli auricolari dalla custodia o tenerli
premuti per 5 secondi.

Spegni :

Rimetti gli auricolari nella custodia o tieni
premuta per 5 secondi.

NL

Aanzetten:

Haal de oordopjes uit de case.

Uitschakelen:

Plaats de oordopjes terug in de case.

4

Power on/off

JP

電源オン :

ケースからイヤフォンを取り出すか、5秒間押し
続けます。

電源を切る :

イヤフォンをケースに戻すか、5秒間押し続けます。

FR

Allumer :

Sortez les écouteurs de l'étui ou appuyez et
maintenez enfoncé pendant 5 secondes.

Éteindre :

Remettez les écouteurs dans l'étui ou appuyez et
maintenez enfoncé pendant 5 secondes.

ES

Encendido :

Saque los auriculares del estuche o mantenga
presionado durante 5 segundos.

Apagado :

Vuelva a colocar los auriculares en el estuche o
mantenga presionado durante 5 segundos.

SE

Ström på :

Ta ut öronsnäckorna från fodralet.

Stäng av :

Sätt tillbaka öronsnäckorna i fodralet.

Correct Wearing



- 1 Ensure the eartip facing downwards.
- 2 Rotate the earbuds back to the auricleside to fit snugly.



Wrong Wearing



- * Eartip facing upwards is the incorrect way to wear the earbuds.



5

Reset

If you accidentally get only one earbud work, or fails to pair each other, please reset it:

1. Turn off Bluetooth and remove/forget [TOZO-A1] records on your device.
 2. Take out both earbuds from the case, and quickly tap them 5 times. Reset is completed when the red lights flash for a second.
 3. Put the earbuds back into case first and take out to reconnect.
- NOTE: If your device displays [Connection failed]. Please delete all [TOZO-A1] pairing history and pair again.




Press 5 times



Charging

Charge the case via USB-C connector.
(USB-C cable included)

- * • • • < 25%
- * * • • 50%
- * * * • > 75%
- * * * * 100%



Don't put wet earbuds into the case,
fully dry off the earbuds before charging.

Thank you for purchasing the TOZO authentic product.

For more latest products, parts and accessories,
please visit: www.tozostore.com

For any assistance please contact Email: info@tozostore.com



RoHS

