


Disney

User's Manual

Spy & Learn Telescope™



**3-6
Years**

vtech®

© Disney
Visit DisneyJunior.com

© 2012 VTech
Printed in China
91-002593-005 US CA

Dear Parent,

At **VTech®**, we know how important the first day of school is for your child. To help prepare preschoolers for this important event, **VTech®** has developed the **Preschool Learning™** series of interactive toys.

Preschool Learning™ features fun characters and inviting school themes that use technology to capture a child's attention and teach important preschool skills like spelling, counting and the alphabet. These vital skills are taught in a way that's both fun and highly engaging to maintain a child's interest. Children will also be introduced to fun school subjects such as art class, music class and even recess! With **Preschool Learning™**, learning is fun from day one!

At **VTech®**, we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting **VTech®** with the important job of helping your child learn and grow!

Sincerely,

Your friends at **VTech®**


To learn more about **Preschool Learning™** series and other **VTech®** toys, visit www.vtechkids.com

INTRODUCTION

Thank you for purchasing the **VTech® Spy & Learn Telescope™**.

Learn letters, numbers, and story-telling skills, or listen to fun pirate rock music! There are three ways to play with the **VTech® Spy & Learn Telescope™**.

- Play interactive games with the LCD screen on the outside of the telescope.
- Look through the telescope for real telescope role-play fun.
- Flip the LCD screen down and look into the telescope to play interactive games and watch stories.



INCLUDED IN THIS PACKAGE


- One VTech® Spy & Learn Telescope™
- One User's Manual

WARNING: All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.

ATTENTION : Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches et étiquettes. Ils ne font pas partie du jouet.

NOTE: Please keep the user's manual as it contains important information.

Unlock the packing locks:




① Rotate the packing lock counter-clockwise 90 degrees.

② Pull out the packing lock.

GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the bottom of the unit.
3. Install 3 new "AAA" size (AM-4/LR03) batteries following the diagram inside the battery box.



(The use of new alkaline batteries is recommended for maximum performance.)

4. Replace the battery cover.

BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

PRODUCT FEATURES

1. ON/OFF BUTTON

Press this button to turn the unit on or off.

2. ANCHOR BUTTON

Press this button to access the menu or move to the next game.

3. MUSIC BUTTON

Press this button to hear fun songs.

4. COMPASS BUTTON

Press this button to choose a game or answer a question.

5. LCD SCREEN

Play games with the LCD screen on the outside of the telescope, or flip the LCD screen down to watch stories and play games while looking inside the telescope.



6. VOLUME CONTROL SWITCH

Slide this switch to adjust the volume.

7. AUTOMATIC SHUT-OFF

To preserve battery life, the **VTech® Spy & Learn Telescope™** will automatically turn off after several minutes without input. The unit can be turned on again by pressing the On/Off button.

ACTIVITIES

1. Skully's Letters

Jake, Izzy, and Cubby are at Skully's birthday party. Help them find a birthday present for Skully. Press the Compass button to answer.

2. Pirate Go Seek

Captain Hook is sneaking around the island, and Jake's on the lookout! Help Jake find the object that Captain Hook is hiding near. Press the Compass button to confirm.

3. Count the Treasure

Jake and his friends have earned gold doubloons by solving pirate problems. Help them count how many gold doubloons they have! Press the Compass button to count along.

4. Take a Look

Watch a fun story unfold. This activity is only available when the LCD screen is flipped down.

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, replace with a new set of batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

For information on this product warranty, please call **VTech®** at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada.

IMPORTANT NOTE

Creating and developing **VTech® Preschool Learning** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S., or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

COPYRIGHT NOTICES:

Copyright ©2012 **VTech**® Electronics North America, L.L.C. All Rights Reserved. **VTech**® and the **VTech**® logo are registered trademarks of **VTech**® Electronics North America, L.L.C. All other trademarks are property of their respective owners.

