


Quick Start Guide




Customer Service Number:

1-800-631-9676 (Toll free for USA & Canada)


Email: support@iliferobot.com



1. Positioning the charging dock.

- Please put the charging dock against a wall and connect the adapter to an outlet. It is suggested to leave an area with at least 4 feet (1 meter) on each side of the charging dock, and at least 8 feet (2 meters) in front of the charging dock. Do not place the charging dock around doors and stairs.
- For optimizing performance of your robot, try best to place the charging dock in an open and uncluttered area.



2. Wake up and charge your robot

- Turn on the power switch at the side of body, then place your robot on the charging dock for a full charge. When charging is finished, lights beside  will turn off.
- Always keep the power switch turned on during your daily use. Turn off the power switch only when you don't use your robot for more than one week.




3. Press on body to wake up robot and press again to begin cleaning.

4. To set up a schedule for your robot, please read carefully the detailed instruction in the user manual. To cancel a schedule, the easiest way is to turn off the power switch at the side of body.

Important tips:

- Remove excess clutter from floors before cleaning (e.g. electronic cords, toys, liquids, etc).



- For better cleaning performance, empty dust tank and clean High Performance Filter after each use (High Performance Filter can't be washed with water). Replace with a new when it is needed.
- In homes with heavily shedding pets, dust tank may fill quickly with fur or hair. In these cases, you may need to empty dust tank and clean filters more frequently.

