



Tip: You need to connect the 6M cable's red trigger wire "A" and "B":

"A" connect reverse lights power DC 12V+.

"B" connect to radio trigger wire.

