


Ultimate C Wired Controller

English



Windows



\* required system: Windows 10 (1903) or above.  
hold X button while connecting the controller to the USB port of your device, wait till the controller is successfully recognized by your Windows, Status LED stays solid.

Raspberry Pi & Android



\* OTG support is required on your Android device, please contact your manufacturer for more information.  
hold B button while connecting the controller to the USB port of your device, wait till the controller is successfully recognized by your device, Status LED stays solid.

Turbo function



\* status LED blinks continuously when the button with turbo functionality is pressed.  
\* D-pad, joysticks are not included.  
hold the button you would like to set turbo functionality to and then press the star button to activate/deactivate its turbo functionality.

Support




Please visit [support.8bitdo.com](https://support.8bitdo.com) for further information & additional support.



猎户座青春版有线手柄

中文



Windows



\* 要求 Windows 设备系统版本为 Windows 10 (1903) 或更高版本。  
按住 X 键并将手柄连接到 Windows 设备的 USB 端口, 等待系统识别完成后, 状态指示灯常亮。

Android / Raspberry Pi



\* 要求 Android 设备支持 OTG 功能, 详情请咨询设备制造商。  
按住 B 键并将手柄连接到 Android / Raspberry Pi 设备的 USB 端口, 等待系统识别完成后, 状态指示灯常亮。

连发功能



\* 已开启连发功能的按键, 按下时状态指示灯会持续闪烁。  
\* 方向键、左 / 右摇杆不支持连发。  
按住需要设置连发的功能键, 再按下星号键可开启 / 关闭连发。

技术支持



\* 请访问 [support.8bitdo.cn](https://support.8bitdo.cn) 了解详细信息。

