


19" SIDE DISCHARGE ROTARY MOWER MODEL: W19T-J

Grass Catcher Model: GC6AA P/N 161018
Repl. Bag: P/N 161158



- | | | |
|----|--------|---------------------------------------|
| 1 | 015818 | Deck 19" |
| 2 | 030023 | Blade - 19" Flat |
| 3 | 041012 | Wheel - 6" Plastic-Diamond |
| 4 | 155234 | Eyebolt - Cable Mounting |
| 5 | 051474 | Cable - Engine/Blade Control |
| 6 | 071076 | Handle - Upper |
| 7 | 071563 | Handle - Lower |
| 8 | 107086 | Handle Bracket - Right Hand |
| 9 | 107094 | Handle Bracket - Left Hand |
| 10 | 109389 | Bail - Engine/Blade Control |
| 11 | 106336 | Washer - Blade Adapter |
| 12 | 106914 | Clip - Trailing Shield |
| 13 | 394619 | Chute Deflector Assembly |
| 14 | 110379 | Cable Tie |
| 15 | 114389 | Trailing Shield |
| 16 | 133231 | Blade Adapter |
| 17 | 144063 | Decal - C.P.S.C. Danger |
| 18 | 001461 | Decal - Blade Warning |
| 19 | 715557 | Decal - Starting Instructions |
| 20 | 156896 | Screw - #10-32 x 3/8 Hex |
| 21 | 150201 | Washer - Curved 5/16 |
| 22 | 150235 | Wingnut 5/16-18 |
| 23 | 150276 | Woodruff Key #6 |
| 24 | 152223 | Nut - Jam Hex 5/16-24 |
| 25 | 151613 | Bolt - Hex Head 10-32 x 1/4 |
| 26 | 150730 | Shoulder Bolt - Wheel |
| 27 | 162024 | Bolt - Blade 3/8-24 x 1-1/4 Gr. 8 |
| 28 | 051219 | Throttle Control |
| 29 | 151928 | Bolt - Curved Head 5/16-18 x 1-3/4 |
| 30 | 152074 | Rope Stop |
| 31 | 152371 | Rope Guide |
| 32 | 452318 | Nut #10-24 HX Nylon Insert |
| 33 | 457168 | Bolt - Hex Head Self Tap 3/8-16 x 7/8 |
| 34 | 457499 | Bolt - Self Tap 1/4-20 x 5/8 |
| 35 | 458687 | Bolt #24 x 1/2 |
| 36 | 715011 | Hairpin Cotter |
| 37 | 715037 | Nut - Keps 1/4-20 |
| 38 | 451492 | Nut - 3/8-16 Toplock |
| 39 | 715607 | Washer - Belleville |
| 40 | 150318 | Clamp - Throttle Cable |
| 41 | 450379 | Bolt - 1/4-20 x 1 3/4 Hex |

- This parts list covers several different mower models; not all of the parts listed may be used on the particular model you are working with.
- When servicing use only **Genuine Factory Replacement Parts (OEM)** that are specifically designed for the particular model that you are working with.
- Parts are right or left hand as viewed from the operator's position.
- Model specifications are subject to change without prior notice.
- **Do not operate** the mower unless all parts are attached and in good working order.
- Lawn mower deck and/or other painted parts differing in color may be substituted without notice.