


MINI DESKTOP FISH TANK USER MANUAL AQ030



Thank you for choosing AQQA products.The AQQA mini desktop fish tank is one of newest style aquarium tank kit. Perfect for a home decoration,office or gifts.

ATTENTION: Gravel, fish, plants and decor are not included.

1.PRODUCT FEATURES

Mini desktop newest style aquarium kit: Simple style for home decor, office or gift.


Perfect for small plants, small fish, goldfish or betta: The aquarium fits almost anywhere. It's the perfect size for small plants, small fish!

ARC-shaped High quality acrylic Aquarium:5 in 1 ARC-shaped fish tank with water recycle、filter 、 beauty lights、 air purification、 Aromatherapy block .


Easy to set up and maintain:The design of this aquarium kit is one click use once connect input voltage DC 5V .

2.INSTRUCTION:

FRONT



BACK



1. Connect USB adapter into the DC 5V power interface,the water pump start work for water recycle and enhance oxygenation.

Please pay attention to the interface is not waterproof.

2.Press switch 1 which the fan begins to circulation and filter the air, and emits the fragrance.

3.Press switch 2 to select the light mode from :White --blue&white-- red--blue--green--multi color 1--multi color 2. and select which color you like.

4.Recommend to replace the water per 1-2weeks,and long press 3 seconds to turn off the switch.

5.Please be minder the MAX/MIN water level to be at the proper level.

3.Troubleshooting

Fault	Cause	Solution
Small or no water outlet	Sponge clogging	Clean or replace sponge
The air outlet has air or no air	The cleaning cotton is blocked	Clean or replace the cleaning cotton
The fragrance becomes light or no fragrant	Failure of aromatherapy block	Change the aromatherapy block
The LED does not work or flashes	Check if it is the adapter matched	Replace LED light board
The fan does not work	Whether the terminal connector is loose or the positive and negative pole are reversed	Replace the fan
Pump not working		Replace the water pump
There is no electricity on the whole		Replace the PCB board

4.MAINTAINING:

To maintain clean acrylic for viewing, please use a piece of dry paper towel to wipe it clean from time to time. When you find the water cloudy, please move the fish into clean water, then replace the water inside the fish tank and clean the filter media inside the filter housing, or replace with new filter media to ensure the fish have a clean and comfortable living environment.

5.PRODUCTS PARAMETER TABLE

Model	Vol.	Lamps	Water pump	Capacity	Dimensions
AQ-030	DC 5V	<7W	3.5W	1.8Gallon/3L	280x120x200mm

6.CAUTIONS:

- 1.Ensure you use an outlet with appropriate voltage.
- 2.The power cord cannot be replaced, stop using if you find the power cord or plug are broken or they are aging and cracking. Return to us for scrap processing and to repurchase a new power supply and new water pump.
- 4.If there is abnormal smell, please unplug before inspecting.
- 5.Ensure the tank is placed on a level surface.
- 6.The LED light is driven by a DC terminal line, please put the DC terminal line into power before turning on .

Power off and unplug the power cord before unplugging the DC terminal line.

Don't connect the power plug before you connect the DC terminal line, it will cause the LED lights to not work. If this occurs, you must unplug and reconnect the power to resume normal operation.

7.WARNING: To guard against injury, basic safety precautions should be observed including the following:


- 1.Read and follow this user manual strictly.
- 2.DANGER-To avoid possible electric shock, special care should be taken since water is employed in the use of aquarium equipment. For each of the following situations, do not attempt to repair yourself. Return the appliance to an authorized service facility for service or discard the appliance.

A.If the appliance falls into the water, DO NOT reach for it! First unplug it and then retrieve it. If electrical components of the appliance get wet, unplug the appliance immediately.

B.Carefully examine the appliance after installation. It should not be plugged in if there is water on parts not intended to be wet.

C.Do not operate any appliance if it has a damaged cord or plug, if it is malfunctioning or if it is dropped or damaged in any manner.

D.To avoid the possibility of the appliance plug getting wet, position aquarium stand and tank to one side of a wall mounted outlet to prevent water from dripping onto the outlet or plug. A “drip loop”, shown in the figure below, should be arranged by the user for each cord connecting an aquarium appliance to the outlet. The “drip loop” is the part of the cord below the level of the outlet, or the connector. If an extension cord is used, to prevent water traveling along the cord and coming in contact with the outlet. If the plug or receptacle does get wet, DO NOT unplug the cord. Disconnect the fuse to the circuit breaker that supplies power to the appliance. Then unplug and examine for the presence of water in the outlet.



3. Close supervision is necessary when any appliance is used by or near children.
4. To avoid injury, do not contact moving parts or hot parts such as lamp bulbs.
5. Always unplug the appliance from the outlet when not in use, before putting on or taking off parts, and before cleaning. Never yank the cord to pull plug from outlet. Grasp the plug and pull to disconnect.
6. Do not use an appliance for other than intended use. The use of attachments not recommended or sold by the appliance manufacturer may cause an unsafe condition.
7. Do not install or store the appliance where it will be exposed to the weather or to temperatures below freezing.
8. Make sure an appliance mounted on a tank is securely installed before operating it.
9. Read and observe all the important notices on the appliance.
10. If an extension cord is necessary, a cord with a proper rating should be used. A cord rated for less amperes or watts than the appliance rating may overheat. Care should be taken to arrange the cord so that it will not be tripped over or pulled.
11. The 2 conductor power cord has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.
12. The appliance is intended FOR HOUSEHOLD USE ONLY. Do not use or mount the appliance in such a way that the top vents are restricted or blocked. These vents are necessary to avoid overheating and ensure safe operating temperatures.
13. SAVE THIS USER MANUAL.

8.PACKAGE INCLUDED:

1x Fish Tank with water pump/filter cotton
1x USB adapter
1x Aromatherapy block
1x Clean cotton
1x Fish net
1×User manual

9.WARRANTY:

1. 1-year free warranty.
2. 1-month free return.
3. Free replacement for 3 months.

10.CONTACT INFORMATION:

Company Name :Shenzhen Aiku Pet Technology Co.,Ltd
Add:Room 501,No.20,Lane 1,Lishipai,Dafapu Community
Bantian Street,Longgang District ,Shenzhen Guangdong. 518000
Email:service@aqqapet.com
Website:http://www aqqapet com



Company Name:E-CrossStu GmbH
Address:Mainzer Landstr.69,Frankfurt am
Main,Hessen,60329
Email:E-CrossStu@web.de
Tel:+49 69332967674



Company Name:YH Consulting Limited
Address:C/O YH Consulting Limited Office
147,Centurion House,London Road,Staines
-upon-Thames,Surrey,London,TW18 4AX
Email: H2YHUK@gmail.com
Tel:+44 07514-677868

