







## **AUTO SAFE MODE** To preserve battery when power is low, the light will enter safe mode with less light output for extra 3 hours. mode cannot be override.

Re arge battery for maximum performance.

## INDICATOR





2. Plug USB cable to USB port

3. Unplug after fully charged

\* Do not charge over 5V.

\* Keep away from flammable objects while charaina. **INDICATOR** 

batterv

## Do not blind the oncoming vehicles. Always adjust the angle

Do not shine light directly into eyes, Do not mount near wireless computer.

WARNING

Do not submerge the light into water.

Understand country lighting laws and regulations before use.

Keep light in cool and dry place when storing.

Fully recharge the light at least every 3 months during storage.

WARRANTY

MOON Lights are covered by a 2-year LIMITED WARRANTY,

while MOON batteries are covered by a 180-day warranty, both starting from the date of purchase.

This warranty covers defects or malfunctions arising from manufacturing or design flaws in the product. It does not cover normal wear and tear, non-rechargeable batteries, and damage caused by improper installation, misuse, mishandling,

accidental loss, abuse, accidents, or nealigence, MOON may require the return of any product submitted for warranty consideration. Customers should contact their authorized

local dealer or authorized regional distributor for warranty service.

For more information, please contact cs@moon-sport.com.

ONLINE WARRANTY REGISTRATION Please visit www.moon-sport.com for online warranty reaistration.

WA-MOON-ORION-W-2401