

Important Safety Instructions

General Safety

General Sarety

I. Resea use this humdline strictly occording to the instructions in
I. Resea use this humdline strictly occording to the instructions in
I. Resea use the law of the control of the control
I. Research of the control of the control
I. Research of th

Operational Safety

Do not add essential oils, water treatment solutions, or water filters to the water tank, as this may damage the humidifier and cause leaks.

Electrical Safety

LINCURLUI SOTETY

1. The input viotage of the humidifier is 100-240V-50/60Hz 1.0.A. Please ensure that the viotage meets the requirements before use.


2. If the humidifier is domoged or malfunctions during operation, please contact customer service or a qualified electricitor for repirary or replacement. Do not ottempt to repair or replace the humidifier yourself.



Specification

Model No.	HC-03		
Adapter Input	100-240V~50/60Hz 1.0A		
Adapter Output/Humidifier Input	12.0V m 1.0A		
Humidifier Power	12W		
Size of the Humidifier	333.0X178.8X178.8mm		


Introduction






Installation and Usage







Provirtec Smart Thermo-Hygrometer Binding

When the humidifier is working, the buttons in the working process will be fully lit, while the buttons not in the working state will not be O on/off

Press turns the humidifier on or off. Each time it is turned on, it will remember previous settings for the operation mode, lighting, and UV stotus. If the water tank is opened or if the water tank is empty during operation, the humidifier will continue to work for 10 minutes before shutting down.

Long press SS enters network connecting mode.



Display/Control Panel



s .888i

 ☐ Humidification Level Settings Press: press repeatedly to cycle through humidification level settings: 1-2-5. Long press: activates filter drying mode, which defaults to 30 minutes. Short press to stop the drying process.

Auto Mode
Press: press outo mode button to activate smart humidity, maintoining indoor humidity within the target ronge. Default humidity is 45-65%, within can be adjusted via the app.

Sleep Mode

Press: turn on or off sleep mode. When activated, it switches to level setting 1 (adjustable). After 3 seconds, the screen and ambient light will turn off. Any button press will reactivate the lights, which will turn off offer 3 seconds and return to sleep mode. When deactivated, the lights will turn on.

UV UV Light

Press: turns the UV light on/off. The UV light will automotically turn off when the water tank is opened.



Press: cycles through designated colors. Long press: turns off the light.

 Auto-shutoff Timer Press: sets the shutoff time, timing duration in the 0-12H cycle, every time you press increase IH. In other modes, a short press will display the current timing time.

⊕ Filter Reset

When the fliter needs replacement, the red fliter light will illuminate. Long press for 3 seconds until the buzzer beeps once to reset the fliter life to 100%.

Display Icon

Display icons					
Icons	Description	Light Status			
888.	Display: humidity, humidification level settings, timing time ombient light settings. Examples of display format: humidity. 000%-100% Timing time: 00H-12H Humidity. 000%-000 or A (Autronové).	White light: Default disploy of humidity. Disploys the humidity level and ambient light setting when adjusting settings returns to humidity disploy after 3s. Disploys timer			

(Auto mode)
Ambient Light: 000-007
or A

S. Dispulys time!
duration when setting,
then returns to
humidity display ofter




Cleaning & Storage Instructions Water Tank Cleaning





Use a clean brush or cloth to gently wipe the inner walls of the water tank to remove any accumulated dirt.







-12-

App Store

a. Download the Prodigytec app from App Store (IOS device) or Google Play (Android device).

App Installation

Free Smart Humidifier. c. Follow the on-screen instructions to odd the Humidifier. d. Add humidifier to unlock more functions. FAQ			The humidifier	outlet and remove them.	
			makes a loud noise.	The high-level humidification setting may make louder noise, please lower the humi operation level.	
Problems	Possible Solution	Ш	Lights up in red.	The filter has been used for a long time. Please clean or replace the filter in time a press and hold \odot for 3 seconds to rechar the filter.	
No mist output.	This humidifier uses evaporative mist-free technology to prevent dampness around the humidifier. The humidification process will not produce visible mist, so please use it with confidence.				
			tank consumes	The humidifier uses more water in cold or environments. This is normal based on	
The air does not seem to be humid.	Please increase the humidification level or increase the set humidity range.	Ш	Quickly. Odor occurs when the humidifier is working.	ambient temperature and humidity.	
				Clean the water tank and filter before use	
	Clean the humidifier before using it again.	П		Check if the adapter is burned out; if so, st	
Humidifier won't turn on or frequently powers off.	Check if the power adopter is properly plugged into the socket and ensure it is not loose. Check for any domage to the adopter; if domaged, stop using the humidifier and contact customer service.	Ш		using and contact customer service.	
		11		Please check whether the humidifier is pla	
		Humidifier leaks.	on a flat surface. If not, the humidifier ma leak from the side.		
			Please check whether the water tank is		
	Please replace the socket and try to turn on the humidifier again.			damaged. If so, please stop using the hum fier until a new water tank is replaced.	

The intake might be too close to the wall, or the intake or outlet could be blocked.

d	The humidifier shuts down after beeping.	The water tank is empty. Refill the tank before turning the humidifier back on.
all, or		Only 2.4GHz WiFi is supported when adding the humidflier. Do not use 5GHz WiFi or dual-band WiFi.
or	Unable to add the humidifier in the app.	The WiFi password is incorrect, please enter the correct password.
oy midifier	0.0 044	The current network status is poor. Please add the humidifier again when the network status is good.
i. e and harge	Unable to use the app to control the humidifier.	Please add the humidifier again according to the on-screen instructions in the app. If you still can't use the app to control the humidifier after adding it again, please contact custom- er service.
or dry	Other problems	If none of the above solutions resolve the problem, please contact customer service.
use. o, stop placed may	subject to the follow (1) This device may (2) This device mus	is with Part 15 of the FCC Rules. Operation is wing two conditions: not couse harmful interference, and, t accept any interference received, including any cause undesired aperation.
s humidi-		or modification not expressly approved by the or compliance could void the user's authority to ent.

12-month warranty for the product.
60-day money-back guarantee for quality issues.
Note: Domages caused by the disregard of this user manual are not subject to warranty.

netp.

To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum 20cm against the relation of the properties of t

Note: This equipment has been tested and found to comply with the limit for a class 8 digital device, pursuant to first 16 of the TCC and the limit for a class 8 digital device, pursuant to first 16 of the TCC and the TCC

Contact Us

At Province, we value your experience. If you have any questions obout our product, please contact us through our store or ago. Our dedicated team will respond promptly to provide you with the support you need. Thank you for choosing Provinter, and we look forward to serving you.

材质: 250G双铜版纸

折好尺寸: 105*150mm

装订方式: 风琴折页

印刷风格:黑白印刷