

vtech®

User's Manual

Lullaby Bear Crib Projector



© 2011 VTech
Printed in China
91-002346-014 US

Dear Parent,

*Ever notice the look on your baby's face when they learn something new through their own discovery? These self-accomplished moments are a parent's greatest reward. To help fulfill them, VTech® created the **Infant Learning**® series of toys.*

*These unique interactive learning toys directly respond to what children do naturally – play! Using innovative technology, these toys react to baby's interactions, making each play experience fun and unique as they learn age-appropriate concepts like first words, numbers, shapes, colors and music. More importantly, VTech®'s **Infant Learning**® toys develop baby's mental and physical abilities by inspiring, engaging and teaching.*

At VTech®, we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting VTech® with the important job of helping your child learn and grow!

Sincerely,


Your friends at VTech®

*To learn more about the **Infant Learning**® series and other VTech® toys, visit www.vtechkids.com*

INTRODUCTION

Thank you for purchasing the **VTech® Lullaby Bear Crib Projector™** crib toy!

The **Lullaby Bear Crib Projector™** will soothe baby into a peaceful sleep. Baby will relax as soothing images project onto the ceiling, while soft melodies, nature sounds and soothing phrases lull baby to sleep. The nursery mode creates a peaceful environment with gentle sing along songs, phrases and melodies. The nature mode will have a softer effect with subtle nature sounds. Press the cute teddy bear button to rotate the melodies, sing along songs or nature sounds.



INCLUDED IN THIS PACKAGE

- One VTech® Lullaby Bear Crib Projector™
- One crib attachment strap
- One instruction manual


WARNING: All packing materials, such as tape, plastic sheets, wire ties and tags are not part of this toy, and should be discarded for your child's safety.

Please loosen the battery cover screws slightly and remove the wire packaging ties.

GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the back of the unit. Use a coin or a screwdriver to loosen the screw.
3. Install 3 new 'AA' (AM-3/LR6) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
4. Replace the battery cover and tighten the screw to secure the battery cover.



BATTERY NOTICE

- Install batteries correctly observing the polarity (+, -) signs to avoid leakage.
- Do not mix old and new batteries.



- Do not mix batteries of different types: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).
- Remove the batteries from the equipment when the unit will not be used for an extended period of time.
- Always remove exhausted batteries from the equipment.
- Do not dispose of batteries in fire.
- Do not attempt to recharge ordinary batteries.
- The supply terminals are not to be short-circuited.
- Only batteries of the same and equivalent type as recommended are to be used.

WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.

With the **VTech® Lullaby Bear Crib Projector™**, safety comes first.


To ensure your child's safety, the assembly of this product is an adult activity, not a child's activity. Please ensure that the crib attachment strap is securely locked into position to avoid injury. Follow the instructions below carefully and make sure the final assembly is correct. Attach only to cribs with sturdy rails and spindles. Do not attach to playpens with mesh walls.

Please make sure the crib attachment strap is out of reach from children when placed in the crib. Please ensure the crib light is positioned in the upright position with the projection light facing directly upwards.

Please remove the crib attachment strap from the unit if it is going to be used outside the crib.

ASSEMBLY INSTRUCTIONS


1. Place the unit in the crib bringing the strap over the top rail. Slip the top of the strap under the slot on the back of the unit and secure. You can adjust the hanging height by choosing the appropriate hole on the top of the strap.
2. Pull slightly on the unit to make sure the strap has been securely fastened. The unit should be snug against the crib rail. Please check the unit frequently to ensure it is still secure.



PRODUCT FEATURES


1. ON/OFF SWITCH

To turn the unit **ON**, slide the **ON/OFF/MODE SELECTOR SWITCH** to the **NURSERY MODE** (👶) or **NATURE MODE** (🌿) position. To turn the unit **OFF**, slide the **ON/OFF/MODE SELECTOR SWITCH** to the **OFF** (●) position.



2. TIMER SWITCH


Slide the **timer switch** to the demo, 5 or 10 minute setting. In the demo mode you will hear a short demonstration of the phrases, sounds, songs and melodies. A soothing image will be projected onto the ceiling for a short time.






3. VOLUME CONTROL

To adjust the volume, press the **LOW VOLUME BUTTON** (🔊) or the **HIGH VOLUME BUTTON** (🔊).



4. LIGHT PROJECTOR SELECTOR

Press the **light projector button** to switch the light projector off and on.




5. AUTOMATIC SHUT-OFF

To preserve battery life, the **VTech® Lullaby Bear Crib Projector™** will automatically power-down without any input after the selected time setting has finished playing. The unit can be turned on again by sliding the timer or mode selector switch.


ACTIVITIES

1. Slide the **on/off/mode selector switch** to turn the unit on. You will hear soothing phrases, sing along songs and soft sounds. A peaceful image will be projected onto the ceiling.





2. Press the **bear button** to hear a soft sing along song and a variety of melodies in the nursery mode. In the nature mode you will hear one of two phrases followed by a variety of melodies. A soothing image will be projected onto the ceiling.



MELODY LIST

1. Brahms' Lullaby
2. Are You Sleeping?
3. My Bonnie Lies Over the Ocean
4. Hush Little Baby
5. Beautiful Dreamer
6. Fur Elise
7. Greensleeves
8. Moonlight Sonata
9. Oh Where Has My Little Dog Gone?
10. Clair de Lune
11. Rock-a-Bye Baby
12. All Through the Night
13. Au Clair de la Lune
14. Shenandoah
15. Twinkle, Twinkle, Little Star
16. Sailing, Sailing



SONG LYRICS

SONG 1

Rock-a-bye baby, on the tree top,
When the wind blows, the cradle will rock.

SONG 2

Twinkle, twinkle, little star,
How I wonder what you are.

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, replace with an entire set of new batteries.



If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

For information on this product's warranty, please call **VTech®** 1-800-521-2010 in the U.S., or 1-877-352-8697 in Canada.

IMPORTANT NOTE:

Creating and developing **Infant Learning** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S., or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.

FCC Notice:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:



- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003.

CET APPAREIL NUMÉRIQUE DE LA CLASSE B EST CONFORME À LA NORME NMB-003 DU CANADA.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.