



Govee Home App

For FAQs and more information,
please visit: www.govee.com

Customer Service

 Warranty: 12-Month Limited Warranty

 Support: Lifetime Technical Support

 Email: support@govee.com

 Official Website: www.govee.com

 @Govee  @govee_official  @govee.official

 @Goveeofficial  @Govee.smarthome

FCC and ISED Canada Statement

This device complies with Part 15 of the FCC Rules and Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil n' doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the

equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

FCC and IC Radiation Exposure Statement

This equipment complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Lors de l'utilisation du produit, maintenez une distance de 20 cm du corps afin de vous conformer aux exigences en matière d'exposition RF.

This Class B digital apparatus complies with Canadian ICES-005. Cet appareil numérique de la classe B est conforme à la norme NMB-005 du Canada.

Responsible party:

Name: GOVEE MOMENTS(US) TRADING LIMITED

Address: 2501 Chatham Rd Suite R Springfield IL 62704

Email: support@govee.com

Contact information: <https://www.govee.com/support>

The trademark Govee has been authorised to Shenzhen Qianyan Technology LTD.
Copyright ©2021 Shenzhen Qianyan Technology LTD.
All Rights Reserved.



User Manual

Model: H70B1

Govee RGBIC Curtain Lights

Safety Instructions

- Move all cribs, beds, furniture and toys away from the lights. Do not tie the bottom of the string lights and form loops as this could wrap around a child's neck and cause SUFFOCATION.
- This product is rated as IP65 Waterproof. It can be used outdoors but cannot be immersed in water.
- The power adapter is rated as IP44 Waterproof. It can be used outdoors but cannot be rinsed or immersed in water.
- The internal light sources of the light bars and strip light cannot be replaced. If the light sources sustain damage, the product should be replaced.
- Do not allow children to assemble and install this product without adult supervision.
- Avoid installing this product near major heat sources.
- External dimmers cannot be used with this product.
- Use this product with the provided power adapter only.
- To reduce the risk of strangulation the flexible wiring connected to this luminaire shall be effectively fixed to the wall if the wiring is within arm's reach.
- Keep all strip lights out of the reach of children.


Introduction

Thanks for choosing Smart Pixel Art Curtain Lights. The string lights are easy to install and can be used both indoors and outdoors. They can not only be used in/on curtains, bedrooms, bushes, dormitories, yards, balconies or any other places for lights and decoration, but also can be applied during holidays like Christmas, Valentine's Day and Halloween. With the DIY mode and Music mode, you can also design your own lighting effects and bring more fun to your parties.


What You Get

Item	Quantity
Curtain Light	1
Adapter	1
Quick Start Guide	1
User Manual	1
Service Card	1

At a Glance



- Press to turn on or off.
- Press and hold for 5 seconds to reset.



Installing Your Device

- Method 1:**
- Choose the target curtain and hang the curtain lights onto.

- Method 2:**
- Clean the surface where you plan to install the lights.
 - Stick the provided VHB gums to the back of the G4 hooks.
 - Stick the G4 hooks to the surface.

- Method 3:**
- Clean the surface where you plan to install the lights.
 - Fix the provided seamless nails to the surface.
 - Hang the curtain lights onto the seamless nails.

Caution: Please ensure the top cable is straight and level. After installing the lights, connect to the adapter and plug into power to test the device.

Pairing Your Light with Govee Home App

What You Need

- A Wi-Fi router supporting the 2.4GHz and 802.11 b/g/n bands. 5GHz is not supported.
- A smartphone or tablet running iOS or Android.



- 1 Download Govee Home app from the App Store (iOS devices) or Google Play (Android devices).
- 2 Turn on the Bluetooth on your smartphone.
- 3 Open the app, tap the “+” icon in the top right corner and search for “H70B1”.
- 4 Tap the device icon and follow the on-screen instructions to complete pairing.

Specifications

Power Input (Adapter)	100-240VAC 50/60Hz
Power Input (Curtain Light)	5VDC 5A
Power Cord Length	13.1ft/4m (Including Control Box)
Size	4.9ft x 6.5ft (1.5m x 2m)
Light Color	RGBIC
Waterproof	Adapter (IP44) Control Box (IPX5) Flood Lights (IP65)
Control Method	App, Control Box, Voice Control
Working Temperature	-10° to 45°C (4° to 113°F)

Troubleshooting

- 1 Fails to connect to Wi-Fi.
 - a. Make sure the distance between the device and the router is less than 100ft.
 - b. Keep as few obstructions (e.g. wall, windows) as possible between the device and the router.
 - c. Make sure the Wi-Fi name and the password you entered is correct.
 - d. Make sure the Wi-Fi you connect to is 2.4GHz. 5GHz is not supported.
- 2 Lost Wi-Fi connection./Cannot use the device with app.
 - a. Make sure your home Wi-Fi works well.
 - b. Check whether the Wi-Fi password has been modified.
 - c. Keep as few obstructions (e.g. wall, windows) as possible between the device and the router.
 - d. Check whether the device has connected to Wi-Fi .
If the device is not connected to Wi-Fi, please re-connect the device to Wi-Fi as mentioned above.
- 3 Cannot pair or connect with Alexa or Google Assistant.
 - a. Ensure the stability of the Wi-Fi connection.
 - b. Go to the app Settings page and follow the instructions under “User Guide” to pair the device again.
- 4 The synchronization effect for Music Mode does not work properly.
 - a. Ensure the control box is close to the music source, which will help the mic pick up sounds better.
- 5 Can multiple users control one device?
 - a. Each device can only be controlled by one account.
 - b. If multiple users want to control the same device, ensure they are using the same account.