

THERMOSTAT INSTALLATION INSTRUCTIONS

1. Remove thermostat cover from base as shown in **FIGURE 1**.
2. If the thermostat is connected to a power source, disconnect it.
3. Locate the thermostat in an area with good air circulation (not on an outside wall).
4. Install the thermostat approximately 5' above the floor.
5. Use electrical wiring approved by applicable codes.
6. Feed wires through the rectangular slots as shown in **FIGURE 2**.
7. Connect the wires to the terminal screws as shown in **FIGURE 3**.
8. Make sure the wiring does not interfere with thermostat's operation.
9. Replace the cover.




FIGURE 1
(front view)

Squeeze sides firmly and lift




FIGURE 2
(back view)




FIGURE 3
(inside view)

WARNING: If this product is used to replace a device containing mercury, the purchaser or consumer must insure that the mercury is properly managed to comply with state or federal regulations. The mercury must not become part of solid waste or waste water. Additional guidance may be obtained from the manufacturer of the product being removed or by calling the Director of Environmental Services.