

2X Fresnel for Bowens Mount

2X-FRESNEL INSTRUCTIONS



Thank you for choosing Angler.

Angler's 6-inch Fresnel lens fits on most lights with a Bowen mount. It employs a ribbed Fresnel lens design to help focus, sharpen, and amplify your beam. The rotating barrel focuses the spread from an intense 12° spot to a broad 40° flood with a smooth falloff from the center hot spot.

Note: This lens's photometrics will change when it's used with different light fixtures.

Precautions

- ▶ Please read and follow these instructions, and keep this manual in a safe place.
- ▶ Clean the unit with only a soft, dry cloth.
- ▶ Make sure that this product is intact and that there are no missing parts.
- ▶ Do not use with lights that output more than 300 W.
- ▶ The lens may become hot during use. Allow time for it to cool before handling or moving it.
- ▶ All images are for illustrative purposes only.

SPECIFICATIONS	
BEAM ANGLE	12° TO 40°
MOUNT	BOWENS
DIMENSIONS	LENS DIAMETER: 6 IN. (15.2 CM) OVERALL: 4.5 × 7.4 × 7.4 IN. (11.4 × 18.8 × 18.8 CM)
WEIGHT	2.3 LB. (1043 G)

Attaching the lens

Insert the lens's mounting tabs into the light's Bowens mount, and turn the lens clockwise until it locks.



Adjusting the Beam Angle

1. Turn the barrel counterclockwise to extend the lens's length and narrow the beam.
2. Turn the barrel clockwise to shorten the lens's length and widen the beam.
3. Mark the position on the beam angle scale to set the same beam angle multiple times.



Unmounting the Lens

Pull the Bowens lock release, and turn the lens counterclockwise. Pull the lens from the light's Bowens mount.



One-Year Limited Warranty

This Angler product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.

To obtain warranty coverage, contact the Angler Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Angler along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense.

For more information or to arrange service, visit www.anglerlights.com or call Customer Service at 212-594-2353.

Product warranty provided by the Gradus Group.

www.gradusgroup.com

Angler is a registered trademark of the Gradus Group.

© 2024 Gradus Group LLC. All Rights Reserved.

