

- 1. Two or more people are needed to complete the installation.
 2. Please protect the wires and remote control accessories from damage during installation.
 - 3. Professional installation is highly recommended. 4. Assemble on a flat, clean and soft surface.

Item no.	Reference Image	Qty.	Item no.	R
1		X1	10	
2		X2	•	
3		X1	1	
4		X1	13	
5		X1	14	
6		X1	15	
7		X1	16	
8		X1	•	
9		X1	18	

Item no.	Reference Image	Qty.
10		X1
		X1
12		ХЗ
13		Х3
14		Х3
15		ХЗ
16		Х3
		X1
18		X1


Item no.	Reference Image	Qty.
19		X1
20		X1
21		X1
22		X1
23		X1
24		X2
25		X2
26		X1

ASSEMBLY INSTRUCTIONS

ASSEMBLY INSTRUCTIONS

Item no.	Reference Image	Qty.
A	4X18mm	X8
B	Ozmania 4X35mm	X4
C	3.5X25mm	X16
D	3000007 4X16mm	Х4
E		X75
F	15X 9.5mm	X37
G	15X12mm	X38
H		X4
I		X8
J		Х8

Item no.	Reference Image	Qty.
K	3.5X12mm	X32
M		X1
N		X1
0		X1
P		X1
Q		X1
R		X11
S		X12




ASSEMBLY INSTRUCTIONS

ASSEMBLY INSTRUCTIONS


USING CAM LOCK AND QUICKFIT

Tighten quickfit until shoulder is flush with panel.Do not overtighten or undertighten.







When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.



Quickfit head should be in the centre of the cam lock when the two panels are joined. Cam lock should be inserted before quickfit.

Turn cam lock clockwise to tighten.





PRE-FIX DRAWER RUNNER INSTRUCTIONS


Pull inner and outer drawer runners apart before fixing them to panels.



Slide drawer runners apart until the drawer lock can be seen, as shown.



Press and hold the drawer runner lock and then continue to slide drawer runners apart, as shown.



Your inner and outer drawer runners are ready to be fixed to panels.



OUTER RUNNER


When installing the outer guide rail, please use the guide rail notch to assemble towards the inner direction of the drawer. Please fix the screws according to the marked position. If the installed position is changed, adjust it side-to-side at the marked position.




When installing the inner guide rail, please use the guide rail notch to assemble towards the inner direction of the drawer. Please fix the screws according to the marked position. If the installed position is changed, adjust it up and down at the marked position.





































































































ASSEMBLY INSTRUCTIONS

ASSEMBLY INSTRUCTIONS




















CONTACT US:

If you have any questions about the installation of products,

just contact us (amazon.com orders only)

1.Log into your Amazon accoun

2.Go to "Your Orders" and find the purchase

3.Click on "Contact Seller"