works with

Add the Permanent Outdoor Lights to your Alexa

* TOTAL * *********

Name and Control Each Device by Voice





What beautiful year light?












■ How to connect to Google Home? Now you can control your Permanent Outdoor Lightwia the alexa app or echol-



. . .


Annual to Say

- -

See-door.














- Failure to connect the Wi-Fi neputrk a Ensure Wi-Fi network is 2.4GHz, not supported SGHz b.Check the Wi-Fi name and password are correct c.Close to the muter for a strong signal.
- The application does not work properly Intorinatal) and reimital) the Smart Life app, then repeat the above steps
- The smart lights can not connect to the application a. Make sare the lights are powered on.

Customer Service

- Warranty: 36-Month Limited Warranty
- Support: Lifetime Texhnical Support
- Email: xuelanmu1121@126.com






































Voice Control Quick Guide for Google Assistant

- After you have successfully connected you can control or best the light with the following commands.
- Hey Google, turn on Permanern Outdoor Lights.
- Hey Google, turn off Permanent Outdoor Lights.

a. Close all apportuning in the background and reopen the Smart Life app






URCAMS

the instruction manual carefully before using and keep it for future ref-


- This light is waterprintf and sultable for outdoor use but is not recommended for use when immersed in water.
- This product supports 2.4Gitg WiFI connection only.
- Long press the remote control switch button 5 seconds the light will Bash and last for 3 minutes, they you can enter APP paining Mode.
- To prevent the light string from falling down, ensure it is installed with both the adhesive type and the citys.
- Tighton up the waterproof cap before using the light.
- Do not allow Children to assemble and install this graduct.
- Acoust installing this product near major heat sources or other danger

Provide professional after sales service. If you have any questions, please feel free to contact us, we will help you solve the problem or prowide new replacement.





At a Glance



	Quantity		Power Input
	50ft = 3-Strings	100ft = 6 Strings 200ft = 12 Strings	PowerInput
	150ft = 9 Strings		
ter	1		Length
sble	1		
	1 bag		Light Display
1	2 big		Working Ten



apter)	100-240VAC 50/60Hz		build lights up white and f
in the	DC24V1A	DC24VL5A	Note Reset if power on it Namote control reset Composite reset butto
nt)	DC24V2A	DC24V2.5A	
	50H	100ft	2.Coper the App and click:
	150h	200h	Taca Make ture your trius
Technology	RG8+AI+W+W		3.Click the device con to:
mure	*-20"to 45"(-4"to 113"F)		4.Enter the WiFi password

Download and Install the App

Search for "Smart Life"or "Tuya Smart" in the app store driwnload and initiall You





The reset made of the equipment is to switch the power supply of the equipment three timestopen-close-open-close-open) Power on the device then press and hold: the power futton on the remote for more than 5 seconds until the device light begins to blink and the device errors the to-be assigned mode. At this point, go to the "Add. Device* page on the APP, you can add the device.

After the device is successfully convex set, the passed device will be displayed on the

main interface. Click to enter the corresponding control inerface.


- When device is online it supports quick operations.
 - When the device is affline, "affline" is displayed, At this time, the device can not be aperated At this time, you can check whether the device has been successfully
 - Click " ALL " . " Bingle " toggle Customize the colors displayed by each led creation endless color combinations, modes and effects for outdoor holiday. ghting year round accent lighting and more.



You can select a favorite dynamic effect from the scene interface or "DY" your die west dynamic effect.

- Clack "Addix" in the top right connects wither custom scene.
- You can DIY their own mode according to their prebisences.
- From care add /determ /modify the color displayed and change the speed of color
- If you we not satisfiest, you can reset the settings.
- After you click "Save" you can see the saved plysomic effects in the same interface.
 - If you want to charge the customize's scene ,click "DIV"to change or delete it.





Enter the music mode and use any device to play music. The but string light will Spring well to the impact.

- The volume of the mobile phone is relatively small, it is better to use Bluetooth. and/o or incal mode.
- Figs can twiect the phone muck or local microphone made according to different use reads.
- You can click your favority scame made to let the led strip light show different music rhythm affects.





ITT VITALE PRODUCTION AND L

FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in

Enter the setting esturface and set the time for the light string to light up according

the interference by one or more of the following measures: . Reorient or relocate the receiving antenna. •Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Pules. Operation is subject to the following two conditions: (1) This device may cause undesired operation.

RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment





