

AIR PURIFIER

USER MANUAL



High Clean Air
Delivery Rate




3-Stage Filtration
System



Low Noise Level



Child Lock



Model: KJ067L

CUSTOMER SERVICE

Our customer service team is standing by to assist you if you have any questions or concerns.



www.mookashops.com



support@mookashops.com



1-855-666-9955



m.me/MookaOnlineShop

CONTENT

SAFETY INFORMATION -----	01
PRODUCT OVERVIEW -----	04
ABOUT THE FILTER -----	05
OPERATING INSTRUCTIONS -----	06
BEFORE OPERATING THE AIR PURIFIER-----	07
OPERATING THE AIR PURIFIER-----	08
INSTALLING & REMOVING FILTERS -----	10
ADD ESSENTIAL OIL -----	11
CLEANING & MAINTAINING -----	12
TROUBLESHOOTING -----	13

SAFETY INFORMATION

READ AND SAVE THESE INSTRUCTIONS



WARNING

Failure to comply with the warnings listed below may result in electric shock or serious injury.

This product should be used only in accordance with the specifications outlined in this manual. Usage other than what has been specified here may result in serious injury.

- 1) The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction(IEC). Children being supervised not to play with the appliance(IEC)
- 2) The appliance is only to be used with the unit provided
- 3) The appliance is only to be used with the recommended vaporizing medium, the use of other substances may give rise to a toxic or fire risk
- 4)This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved(EN). Children shall not play with the appliance(EN). Cleaning and user maintenance shall not be made by children without supervision(EN)
- 5)When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:


SAFETY INFORMATION

- Read all instructions before using appliance.
- To avoid fire or shock hazard, plug the appliance directly into a right AC electrical outlet.
- Keep the cord out of heavy traffic areas. To avoid fire hazard, NEVER put the cord under rugs, near heat registers, radiator, stoves or heaters.
- To protect against electrical hazards, DO NOT immerse in water or other liquids. Do not use near water.
- Children cannot recognize the hazards associated with the usage of electrical appliances. For this reason, always supervise children when they are near the unit.
- Always unplug the air purifier before moving it, opening the grill, changing filters, cleaning or whenever the air purifier is not in use. Be sure to pull by the plug and not the cord.
- NEVER drop or insert any object into any openings.
- DO NOT run cord under carpeting.
- DO NOT cover cord with throw rugs, runners, or similar coverings.
- DO NOT route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
- DO NOT operate any appliance with a damaged adapter, if motor fan fails to rotate, after the appliance malfunctions, or if it has been dropped or damaged in any manner. Send to Customer Service for assistance.
- Use appliance only for intended household use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons.
- Unplug or disconnect the appliance from the power supply before servicing.
- WARNING: To Reduce The Risk Of Fire Or Electric Shock, Do Not Use This Fan With Any Solid-State Speed Control Device.
- WARNING: To Reduce The Risk Of Fire, Electric Shock Or Injury To Persons, Do Not Use Replacement Parts That Have Not Been Recommended By The Manufacturer (e.g. Parts Made At Home Using A 3D Printer).

SAFETY INFORMATION

- DO NOT use outdoors.
- DO NOT place anything on top of unit.
- NEVER block the air openings, grills/outlets or place on a soft surface such as a bed or sofa, as this could cause the unit to tip over, blocking the air intake or outtake opening.
- DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void your warranty. The inside of the unit contains no user serviceable parts. All servicing should be performed by qualified personnel only.
- WARNING: To reduce the risk of fire or electric shock, do not use this device with any solid-state speed control device.
- Only use original supplied power adaptor.
- WARNING: To Reduce The Risk Of Fire, Electric Shock Or Injury To Persons, Do Not Use Replacement Parts That Have Not Been Recommended By The Manufacturer (e.g. Parts Made At Home Using A 3D Printer)

PRODUCT OVERVIEW




Notice:


If product is damaged or missing any parts, call customer service at 1-855-666-9955.

ABOUT THE FILTER

3 Stage Filter



OPERATING INSTRUCTIONS



CONTROL PANEL

BEFORE OPERATING THE AIR PURIFIER


1. Carefully lift your air purifier from box and **remove the two plastic bags** for wrapping unit and filter.

2. Select a firm, level and flat location for the air purifier.


*For proper air flow, locate the unit at least 1 foot from any wall or furniture.

*Make sure none of the grills are blocked.


3. Plug the supplied power adaptor into a right voltage AC outlet.




Invert the unit and rotate anticlockwise to open the bottom cover.



Take out the filter from the air purifier.



Remove the packaging bag from the filter and insert it into the unit.



Rotate clockwise to lock the bottom cover.

OPERATING THE AIR PURIFIER



POWER BUTTON


Press this button to turn on/ off the unit.



FILTER RESET


The filter should be replaced every 3-6 months.

"  " indicator flashes when the filter replacement is needed.

After the filter has been replaced, press and hold the  button for 3 seconds to reset the filter lifetime counter.



SLEEP MODE

Press the  button to turn on sleep mode. Under SLEEP mode, all the lights (except sleep indicator) will turn off and unit working in sleep speed.

OPERATING THE AIR PURIFIER



NIGHT LIGHT BUTTON

Press this button to turn on / off the night light mode.



SPEED BUTTON

Press the button each time to select ☾ (sleep mode),
1 (Low), 2 (Medium) and 3 (High) speed.



TIMER BUTTON

Cycle through timer options by press this button, the purifier can be
timed to operate for 1, 2, 4, 8 hours.



CHILD LOCK MODE

Long press ☾ button for 3S to enter or exit the child lock mode.

IMPORTANT NOTE:

When the unit is not in use, please switch it off and unplug it.


INSTALLING & REMOVING FILTERS

FILTER REPLACE INDICATOR

The filter should be replaced every 3-6 months.

The FILTER RESET indicator  lights up when the filter replacement is needed.



Follow the instruction below to change filter and reset the program.

1. Invert the unit and rotate anticlockwise to open the bottom cover.
2. Take out the old filter from the air purifier.
3. Remove the packaging bag from the new filter and insert it into the unit.
4. Rotate clockwise to lock the bottom cover.
5. Press and hold the  button for 3 seconds to reset the filter lifetime counter.

ADD ESSENTIAL OIL

To fresh your home, you can add essential oil.

1. Use your thumb to push the cover outward and flip it over to open the aroma cover.
2. Add 4-6 drops of essential oil to the aroma pad.
3. Flip the aroma cover down and push it inward to lock it.



CLEANING & MAINTAINING

WARNING

Unplug or disconnect the appliance from the power supply before cleaning.

The machine should be cleaned at least once every month by a clean, dry, soft cloth.

More frequent cleaning may be required depending on environmental conditions.

NOTE:

Do NOT stick any foreign objects or your fingers inside of the unit.

Do NOT use gasoline, benzine, thinner, harsh cleaners, etc. on and/or in the unit while cleaning as they will damage the product.

NEVER use alcohol or other solvents.

PACKAGE CONTENTS

1* Air Purifier

1* HEPA Filter
(Pre-Installed)

1* User Manual

1* Power Adapter

SPECIFICATIONS

Model No.: KJ067L

Rated Voltage: DC12V


Rated Power: 4W

Dimensions: 6.3*6.3*9 in.


Weight: 2.03 lb

TROUBLESHOOTING

If the appliance works not properly please check the most common problems you could encounter at the table below.

Problem	Possible solution
No power adapter	Please open the bottom cover and take out the power adapter.
	If you do not find the adapter inside the air purifier, please contact customer support.
The appliance does not work	Please check if the power cord is plugged into the socket properly.
	Please check if the bottom cover is installed properly.
	Check to see if the power adapter is damaged. If it is, stop using the air purifier and contact customer support.
	Plug the air purifier into a different outlet. If still not working, please contact the customer support.
	The air purifier may be malfunctioning. Contact the customer support.
Odor cannot be removed.	Check if the filter is installed properly. Please ventilate the operating area before purifying.
	The filter is dirty. Please replace the filter.
"  " is still on after replacing the filter.	Reset the Check Filter Indicator.

TROUBLESHOOTING

Strange smell coming from the air purifier	Replace the filter if necessary.
	Please replace the new aromatherapy pad.
	Make sure not to use your air purifier in an area with high humidity or while diffusing essential oils.
	Contact the customer support.
The air purifier makes an unusual noise while the fan is on.	Make sure the filter is properly in place with the plastic packaging removed.
	The filter is dirty, please replace the filter.
	The air purifier may be damaged or a foreign object may be inside, please contact customer support.
Poor air purification quality	Tap "  " to increase the fan speed.
	Make sure no objects are blocking the sides or top of the air purifier (the inlet or outlet).
	Make sure the filter is removed from its packaging and properly in place.
	Close doors and windows while using the air purifier.
	Replace the filter.
	If the room too larger, air purification will take longer.

Note:


1. To effectively clean air, keep windows and doors closed while the air purifier is on.
2. If your problem is not listed, please contact Customer Support to get the solution firstly.

mooka

Beyond Elegance

 www.mookashops.com

 support@mookashops.com

 1-855-666-9955

 m.me/MookaOnlineShop



Made in China