


User manual

The UK1 has four keys; Open, Close, Trunk and Frunk. On each button press it initiates the communication to the MUB1 and the range measurement process.



Lock Button

- To unlock the vehicles doors when the button is pressed short.

Unlock Button

- Locks the vehicles doors when the button is pressed short.

Frunk Button

- To unlock and open the vehicles front trunk lid.

Trunk Button

- To unlock and open the vehicles trunk lid.

In case the battery is low, car access is possible by means of integrated NFC technology.

MARQUARDT GmbH Schloßstraße 16 D 78 604 Rietheim - Weilheim	Initial Version	10.11.2024	Version	1.0
	Department	RDEC-PU	Datei	
	Editor	Hrishikesh Nirgude	Doku.-Nr.	
	Revision		Seite	Seite 1 von 1