# **Quick Setup Guide**









## Safety



## **A** WARNING:

STRANGULATION HAZARD — Children have STRANGLED in cords.

NEVER attempt to use cord without the protective covering. Check protective covering before each use to ensure that the cord is not exposed to your child. Immediately discontinue use if protective covering is damaged or broken. This device is designed for indoor use only. This device is designed to be used behind a standard crib and against the wall only.

Use only the AC power supply included with your Becky AI. Adult assembly is required. Keep small parts away from children when assembling. This product cannot replace adult supervision. Ensure your child's health by checking him/her regularly. This product is not a toy. Do not allow children to play with it.

DISCLAIMER — Becky AI Baby Monitor was created to help parents track factors that affect their baby's sleep schedule and general wellbeing. It is not intended to cure, treat, or prevent any disease or health condition, including but not limited to Sudden Infant Death Syndrome (SIDS). No baby monitor can ever replace you as a caregiver, or substitute for asking your doctors for medical advice.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause

undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to

-02-

comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio

frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- --Reorient or relocate the receiving antenna.
  --Increase the separation between the equipment and
- receiver.
  --Connect the equipment into an outlet on a circuit
- different.

measures:

technician for help.

from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV

NOTE: This device and its antenna (s) must not be co-located or operation in conjunction with any other antenna or transmitter.

## RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna (s) must not be co-located or operation in conjunction with any other antenna or transmitter.

# In the Box



Buzzer×2







Lens-

Invisible IR

Screw nut

Positioning Paper

**Power Cord** 




-05-






# What you'll need



Position the crib against the preferred wall in the nursery.

IMPORTANT: CRIB CENTER MUST BE IN A STUD-FREE AREA OF THE WALL.




-07-


-08-


2. Using the Measuring Tape, find the center of the crib and mark the wall with a pencil.


Notes: Center of crib must be within 1.8m (6ft) of an electrical outlet. Then, move the crib away from the wall.





 Step on the bottom of the Measuring Tape so it aligns with the floor and your "Crib Center" mark on the wall. Lift the tape up 1.5m (5ft) and mark on the "Mark Here" indicator.












Connect the Power Cord to the Power Supply. Plug the Power Cord into the nearest outlet. Once the power button light turns on, you're ready to go.



#### Notes:

- 1.The distance between Becky Al and baby is no more than 1.4m (4.6ft).
- 2.The effective monitoring angle is horizontal 120°.

In order to ensure that the crib is fully monitored by radar, please check after adding the device to the APP.



-20-

#### **Download APP**

Search "Becky AI" in the App Store or scan the QR code below to download and install.










Open "Becky Al" App, click "Register" option, select the phone number or email to register.

#### Notes:

Power Up Your Camera: Plug in your camera and place it in the area you'd like to monitor. Make sure the area has a strong Wi-Fi signal.



-21-

-22-

Enter your phone number or email address, then pass the verification code to finish the registration.

"mine".

Notes: Please open the location settings of the APP, otherwise the device hotspot cannot be searched.

After logging into your registered account, click the



-23-

-24-

Click "Bind the device", to add the device.



#### -25-

#### Scan QR Code

1. Press the camera reset button for 3-5 seconds, then you can hear "Reset successful".



-26-

2. Select 2.4GHz network and enter the LAN password, then click the "Next Step".



3. Place the QR code towards the camera lens. Place it 15cm (0.49ft) to 20cm (0.7ft) from the lens.

Notes: If the device fails to scan the code, click "Wi-Fi direct Mode" to add the device (page 28 details)





-27-

-28-

### 4. Finally add the device successfully.



#### AP Connection

 Click "Wi-Fi direct Mode" to connect the device in AP mode.



-29-

-30-

Click "Find it", connect to the LAN of "LLM\_xxx", and then enter the password: 12345678

Connect to a horizont

-31-

3. Select 2.4GHz network and enter the LAN password, then click the "Next Step".



-32-

4. Finally add the device successfully.

