

Stylus Pen C37-R

Button

Type-C Charging port

Indicator light

Built-in Battery

Replaceable nib

User Manual

Please carefully use this user manual before using and keep it well for future using.

Compatible with 2018-2024 iPad

iPad Pro 11 inch 1. Gen-2018	A1980/A2031/A1934/A1979
iPad Pro 11 inch 2. Gen-2020	A2238/A2082/A2040/A2231
iPad Pro 11 inch 3. Gen-2021	A2377/A2459/A2376/A2460
iPad Pro 11 inch 4. Gen-2022	A2479/A2433/A2476/A2462
iPad Pro 12 inch 3. Gen-2018	A1876/A2014/A1895/A1981
iPad Pro 12 inch 4. Gen-2020	A2294/A2060/A2292/A2293
iPad Pro 12 inch 5. Gen-2021	A2378/A2461/A2379/A2462
iPad Pro 12 inch 6. Gen-2022	A2464/A2467/A2468/A2469
iPad Air 10.5 inch 1. Gen-2019	A2152/A2153/A2154/A2155
iPad Air 10 inch 4. Gen-2020	A2316/A2322/A2325/A2072
iPad Air 10 inch 5. Gen-2022	A2388/A2290/A2391
iPad Mini 7.9 inch 5. Gen-2019	A2133/A2124/A2126/A2125
iPad Mini 8.3 inch 6. Gen-2021	A2367/A2368/A2369
iPad 9.7 inch 7. Gen-2018	A1929/A1954
iPad 10.2 inch 7. Gen-2019	A2197/A2200/A2198
iPad 10.2 inch 8. Gen-2020	A2270/A2428/A2429/A2430
iPad 10.2 inch 9. Gen-2021	A2302/A2304/A2305/A2306
iPad 10.9 inch 10. Gen-2022	A2696/A2757/A2777
iPad Air M2 11 inch-2024	A2692/A2693/A2694
iPad Air M2 12.9 inch-2024	A2698/A2699/A2695
iPad Pro M4 11 inch-2024	A2838/A2837/A3006
iPad Pro M4 13 inch-2024	A2926/A2926/A3007

Not compatible with 2017 and earlier iPads

iPad (1 ~ 5. Gen)-2010~2017	A1219/A1337/A1396/A1395 A1397/A1416/A1430/A1403 A1458/A1459/A1460/A1822 A1823
iPad Mini (1 ~ 4. Gen)-2012~2015	A1432/A1454/A1455/A1489 A1490/A1491/A1599/A1600 A1538/A1550
iPad Air (1 ~ 2. Gen)-2013~2014	A1474/A1475/A1476/A1566 A1567
iPad Pro 9.7 inch-2016	A1673/A1674/A1675/A1701
iPad Pro 10.5 inch-2017	A1709/A1852/A1854/A1652
iPad Pro 12.9 inch (1 ~ 2. Gen)-2015~2017	A1670/A1671/A1821
Other	iPhone, Samsung, Huawei, Microsoft, Surface, Lenovo, Acer, Dell, Xiaomi, other brands

Bluetooth

After linking the Bluetooth
***One-Click: Open multitasking;**
***Double-click: Back to home page;**
***View real-time pencil battery level.**

turn on iPad pen> bluetooth
 Bluetooth name: ipencil

ipencil

How to add widget to show battery level on iPad?

Screen swipe right from left
 Side>Edit-->Battery>Add widgets

Function

Press the pen switch for 2 seconds, the indicator light will be light on quickly. when you press again, the indicator light will be shut off. The stylus pen standby for 20 mins then will be automatically shut off.

Instructions for use

- The iPad version is no less than 12.2 .
- Open the settings memo-close apple per Graffiti function.
- Turn on settings Bluetooth and turn off the connection of the original apple pen. (after setting above, you can use the product normally.)

*Go to Settings>Apple pencil>Close
 Only Draw with Apple Pencil

Button

Indicator light

Use the USB-C cable for pen charging.
 Connect the end to the pen connector and the other end to a computer, adapter, or other device.

Includes: USB Adapter

Removable nib for easy replacement.

No need to worry about wear and tear!
 (Simply twist the tip for easy removal/installation).

Instructions for use

Tilt Sensitivity

You can change the size of the brush by changing the tilt angle of the pen on the iPad. Please note that not all brush types are tilt-sensitive (e.g. the fountain pen tool). If you have any question during use, please feel free to contact us.

*No pressure sensitivity

Magnetic design

Our iPad pen can be magnetically attached to the iPad, making it very easy to carry.

*Doesn't support magnetic charging

Palm Rejection

With the palm rejection, you can naturally rest your palm on the iPad when drawing and writing without accidentally operating it.

Charging indication

- 70 ~ 100% Green Light
- 20~70% Blue light
- 5 ~ 20% Red light (below 5% red light blinking)

Product Specification

Product Name	Stylus Pen (Bluetooth style)
Main Functions	Drawing, Writing, Taking Notes, Touching
Materials	Aluminum alloy pen body(POM plastic pen nib)
Measurement	Ø9.0mm pen body and Ø1.5mm pen nib *168mm
Using Hours	16 hours
Charging Time	15min
Sleeping Protect	20 Mins do not using Pencil will turn off
Product Colors	Multi-colour
Standard Accessories	USB-C to USB-C charging cable
Package	Charging Cable, User Manual

Common Faults & Solutions

Faults	Solutions
Lag, Delay	1. Check that the nib is fitted properly and try again
	2. Replace the nib with another one and try again
	3. Check that the steel screen protector is not badly damaged or too thick
	4. Restart iPad and try again
Cannot write	1. Check that the pen is turned on
	2. Check that the pen is compatible with the iPad
	3. Check that the app supports the writing function
	4. Check that the iPad is connected to the original pencil. If so, disconnect it
Won't turn on	1. Check that the pen is powered off
	2. Use the pen in accordance with the user manual

Stylus Pen C37-R

Kompatibel mit 2018-2024 iPad

iPad Pro 11 inch 3. Gen -2018	A1980/A2013/A1934/A1979
iPad Pro 11 inch 4. Gen -2020	A2238/A2604/A2302/A2314
iPad Pro 11 inch 5. Gen -2021	A2377/A2450/A2301/A2460
iPad Pro 11 inch 6. Gen -2022	A2598/A2435/A2761/A2762
iPad Pro 12 inch 3. Gen -2018	A1978/A2013/A2232/A2333
iPad Pro 12 inch 4. Gen -2020	A2129/A2604/A2195/A1983
iPad Pro 12 inch 5. Gen -2021	A2378/A2461/A2379/A2462
iPad Pro 12 inch 6. Gen -2022	A2599/A2436/A2763/A2764
iPad Air 10.5 inch 3. Gen -2019	A2152/A2123/A2153/A2154
iPad Air 10.9 inch 5. Gen -2022	A2388/A2589/A2191
iPad Mini 7.9 inch 5. Gen -2019	A2133/A2124/A2126/A2125
iPad Mini 8.3 inch 6. Gen -2021	A2367/A2568/A2369
iPad 9.7 inch -2018	A1934/A1948
iPad 10.2 inch 7. Gen -2019	A2197/A2200/A2198
iPad 10.2 inch 8. Gen -2020	A2270/A2428/A2429/A2430
iPad 10.2 inch 9. Gen -2021	A2302/A2569/A2303/A2605
iPad 10.9 inch 10. Gen -2022	A2696/A2757/A2771
iPad Air M2 13 inch -2024	A2692/A2634/A2694
iPad Air M2 11 inch -2024	A2698/A2699/A2690
iPad Pro M4 11 inch -2024	A2698/A2637/A3000
iPad Pro M4 13 inch -2024	A2695/A2636/A3007

Nicht kompatibel mit 2017 und früheren iPads

iPad (1. - 5. Gen) -2010-2017	A1129/A1337/A1396/A1395 A1397/A1416/A1430/A1403 A1458/A1459/A1460/A1822 A1823
iPad Mini (1. - 4. Gen) -2012-2015	A1432/A1454/A1455/A1489 A1490/A1491/A1599/A1600 A1518/A1550
iPad Air (1. - 2. Gen) -2013-2014	A1474/A1475/A1476/A1566 A1567
iPad Pro 9.7 inch -2016	A1673/A1674/A1675/A1701
iPad Pro 10.5 inch -2017	A1709/A1852/A1854/A1652
iPad Pro 12.5 inch (1. - 2. Gen) -2015-2017*	A1676/A1677/A1821
Other	iPhone, Samsung, Huawei, Microsoft, Surface, Lenovo, Acer, Dell, Xiaomi, other brands

Benutzerhandbuch

Bitte lesen Sie dieses Benutzerhandbuch vor dem Gebrauch sorgfältig durch und bewahren Sie es für die spätere Verwendung gut auf.

Wie fügt man ein Widget zur Anzeige des Batteriestatus auf dem iPad hinzu?

Wischen Sie von der linken Seite des Bildschirms nach rechts > Editieren > + > Batterie > Widgets hinzufügen

Gebrauchsanweisung

- Die iPad-Version ist nicht unter der Version 12.2.
- Öffnen Sie die Einstellungen
- Bluetooth öffnen und die ursprüngliche Apple Pencil-Verbindung deaktivieren. (nach der Einstellung oben, können Sie das Produkt normal verwenden.)

*Gehen Sie zu Einstellungen> ApplePencil>Nur mitApple Pencil zeichnenshließen

Funktion

2 Sekunden lang auf den Stiftschalter drücken, die Anzeigeleuchte leuchtet schnell auf. Wenn erneut gedrückt wird, erlischt das Licht. iPad Stift hat einen Energiesparmodus, 20 Minuten der Nichtbenutzung automatisch abgeschaltet.

Hinweise zur Verwendung

Neigungsempfindlichkeit

Sie können die Größe des Pinsels ändern, indem Sie den Neigungswinkel des Stifts auf dem iPad ändern. Bitte berücksichtigen Sie, dass nicht alle Pinseltypen neigungsempfindlich sind (z. B. der Füllfederaler Werkzeug).

Wenn Sie während der Nutzung irgendeine Frage haben, können Sie uns gerne kontaktieren

*Keine Druckempfindlichkeit

Magnetisches Design

Unser iPad-Pencil kann magnetisch am iPad befestigt werden, wodurch er sehr leicht zu tragen ist.

Handflächenabweisung

Mit der Handflächenabweisung können Sie Ihre Handfläche beim Zeichnen und Schreiben ganz natürlich auf das iPad legen, ohne es versehentlich zu bedienen.

Anzeige des Ladezustands

70-100% Grünes Licht
20-70% Blaues Licht
5-20% Rotes Licht (unter 5% blinkt das rote Licht)

Spezifikation des Produkts

Name des Produkts	Stylus Pen (Bluetooth-styl)
Funktion	Zeichnen, Schreiben, Notizen machen, Berühren
Materialien	Stiftgehäuse aus Aluminiumlegierung (Spitze aus POM-Kunststoff)
Messung	9,0 mm Stiftspitzebreite und 1,5 mm Stiftspitze -168mm
Betriebsstunden	16 Stunden
Aufladezeit	15 Minuten
Schützen im Schlaf	Bei 20 Minuten Nichtbenutzung schaltet sich der Pencil aus
Produktfarben	Mehrfarben
Standard-Zubehör	USB-C-auf-USB-C-Ladekabel
Paket	Ladekabel, Benutzerhandbuch

Häufige Fehler & Lösungen

Fehler	Lösungen
Verzögerung Rückstand	- Überprüfen Sie, ob die Spitze richtig eingesteckt ist und versuchen Sie es erneut - Tauschen Sie die Spitze gegen eine andere aus und versuchen Sie es erneut. - Überprüfen Sie, ob der Bildschirm Schutz aus Stahl nicht stark beschädigt oder zu dick ist. - Starten Sie das iPad erneut und versuchen Sie es erneut
Nicht schreiben können	- Überprüfen Sie, ob der Stift eingeschaltet ist - Überprüfen Sie, ob der Stift mit dem iPad kompatibel ist - Überprüfen Sie, ob die App die Stiftfunktionen unterstützt - Überprüfen Sie, ob das iPad mit dem Original-Stift verbunden ist. Wenn ja, trennen Sie es
Nicht einschalten	- Überprüfen Sie, ob der Stift ausgeschaltet ist - Benutzen Sie den Stift entsprechend des Benutzerhandbuchs

In China hergestellt

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that

to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

	Charging indication	
		70 ~ 100% Green Light
		20 ~ 70% Blue Light
		5 ~ 20% Red light (below 5% red light blinking)
Product Specification		
Product Name	Stylus Pen (bluetooth style)	
Main Functions	Drawing, Writing, Taking Notes, Touching	
Materials	Aluminum alloy pen body and POM plastic pen nib	
Measurement	Ø9.0mm pen body and Ø1.0mm pen nib *168mm	
Using Hours	16 hours	
Charging Time	15min	
Sleeping Power	20 Mins do not using pen will turn off	
Product Colors	Multi-colour	
Standard Accessories	USB-C to USB-C charging cable	
Package	Charging Cable, User Manual	

Common Faults & Solutions	
Faults	Solutions
Lag, Delay	1. Check that the nib is fitted properly and try again 2. Replace the nib with another one and try again 3. Check that the steel screen protector is not badly damaged or too thick 4. Restart iPad and try again
Cannot write	1. Check that the pen is turned on 2. Check that the pen is compatible with the iPad 3. Check that the app supports the writing function 4. Check that the iPad is connected to the original pencil. If so, disconnect it
Won't turn on	1. Check that the pen is powered on 2. Use the pen in accordance with the user manual

Made in china

Name des Produkts	Stylus Pen (Bluetooth style)
Hauptfunktionen	Zeichnen, Schreiben, Notizen machen, Schreiben
Materialien	Stiftgehäuse aus Aluminiumlegierung (Spitze aus POM-Kunststoff)
Messung	9,0 mm Stiftgehäuse und 1,5 mm Spitze *168mm
Betriebsstunden	16 Stunden
Aufladezeit	15 Minuten
Schützen im Schlaf	Bei 20 Minuten Nichtbenutzung schaltet sich der Pencil aus
Produktfarben	Mehrfarben
Standard-Zubehör	USB-C-zuf-USB-C-Ladekabel
Paket	Ladekabel, Benutzerhandbuch

Häufige Fehler & Lösungen	
Fehler	Lösungen
Verzögerung Rückstand	1. Überprüfen Sie, ob die Spitze richtig eingesteckt ist und versuchen Sie es erneut.
	2. Tauschen Sie die Spitze gegen eine andere aus und versuchen Sie es erneut.
Nicht schreiben können	1. Überprüfen Sie, ob der Bildschirm sauber aus Stahl nicht stark beschlagelt oder zu dunkel ist.
	4. Starten Sie das iPad erneut und versuchen Sie es erneut.
Nicht einschalten	1. Überprüfen Sie, ob der Stift eingeklappt ist.
	3. Überprüfen Sie, ob der Stift mit dem iPad kompatibel ist.
	3. Überprüfen Sie, ob die App die Schreibfunktion unterstützt.
	4. Überprüfen Sie, ob das iPad mit dem Original-Stift verbunden ist. Wenn ja, trennen Sie es.
	1. Überprüfen Sie, ob der Stift eingeklappt ist.
	2. Tauschen Sie den Stift entsprechend des Benutzerhandbuchs

In China hergestellt