

airwrap i.d.

User manual




SV12 JN.00000 PN.000000-00-00
00.00.00 VERSION NO.01

In the box
Getting started
Connecting to the MyDyson™ app
Using your attachments
Pre-styling
Curling

Shaping
Volumising
Smoothing
Diffusing
Stretching
Regular filter maintenance

dyson

In the box



Dyson Airwrap i.d.[™]
multi-styler and
dryer main body



Conical
Airwrap[™]
barrel



40mm
Airwrap[™]
long barrel




Dryer+
Flyaway
smoother



Fast dryer



Filter
cleaning
brush




Large
volumising
round brush



Soft
smoothing
brush

You can buy additional attachments at www.dyson.com.au/co.nz



40mm
Airwrap[™]
barrel



30mm
Airwrap[™]
barrel



30mm
Airwrap[™]
long barrel



20mm
Airwrap[™]
barrel



Firm
smoothing
brush




Small soft
smoothing
brush




Small firm
smoothing
brush




Small round
volumising
brush




Round
volumising
brush



Wide-tooth
comb



Blade
concentrator



Diffuser



Wave+ Curl
diffuser


Getting started




Temperature control
Three temperature settings including constant cold.



Airflow control
3 airflow speeds.



Power on/off
Sliding switch



i.d. curl™ personalised curling sequence
Complete the tutorial in the MyDyson™ app to unlock this feature. Slide up and release to activate.

Removable filter cage
Easy to remove for cleaning (see the 'Regular filter maintenance' section for details).



LED
Flashing blue – ready to connect.

Constant blue – connected.

Clean the filter.
See the 'Regular filter maintenance' section for details.

If the red LED lights, and the filter has already been cleaned, contact the Dyson Helpline.

Unlock i.d. curl™ personalised curling sequence by connecting to the MyDyson™ app

Download on the App Store. Get it on Google Play.

Step 1

Download the MyDyson™ app and create your account.
If you already have an account, log in.

Step 2


Power on your Dyson Airwrap i.d.™ multi-styler and dryer and add machine to the app.
Bluetooth® wireless technology must be enabled on your mobile device.

Step 3

Follow the steps to pair your Airwrap i.d.™.
Airflow will be active during this time.

Step 4


Once paired, power off your Airwrap i.d.™.
Continue set-up in the app to enable features such as the i.d. curl™ personalised curling sequence.



MyDyson™ app connectivity

App functionality may vary per market. Requires internet connection.
Operating system and mobile device requirements for the MyDyson™ app can be found on the App Store or Google Play.


Apple, the Apple logo and Siri are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of the Apple Inc., registered in the U.S. and other countries. Google Play, the Google Play logo, Google Assistant are trademarks of Google Inc.



Using your attachments


Connecting the attachment

Turn attachment into the main body until it fits securely.




Changing attachments

To change attachment, pull down on the switch to release.



Cool touch tip


During use, the Dyson Airwrap™ barrels, round brushes and Dryer+Flyaway smoother will get hot. To change to another attachment, hold the tip.



Take care when handling hot attachments

Hold the attachment only in the area indicated.
Some attachments may need occasional cleaning.


For more information, go to
www.dyson.com.au/co.nz



Dryer+Flyaway smoother



Conical Airwrap™ barrel



Round volumising brush


Pre-styling

For straight and wavy hair, use a dryer attachment – Fast dryer or Dryer+Flyaway smoother.

The Dryer+Flyaway smoother has two modes (i) drying and (ii) smoothing. Use the cool tip to switch between the modes.

Hair should look dry but feel cold to the touch before curling with barrels.

For curly and coily hair, use the Firm smoothing brush. Brush hair downwards in small sections, starting from the ends and working towards the roots, until slightly damp to touch.




Curling

Using i.d. curl™ sequence

The Dyson Airwrap i.d.™ multi-styler and dryer remembers your personalised i.d. curl™ sequence. This tailors wrapping and styling times to your personal hair profile, using the MyDyson™ app.


Slide up and release the power switch to activate i.d. curl™ sequence, following initial app set-up.



Barrels


Step 1

Take a section of hair and bring barrel towards tips. Hair will start to wrap around barrel.



Step 2

Move styler towards head, no need to twist. Your personalised i.d. curl™ sequence will run.




Step 3

Cold shot will automatically activate to set the curl. Airflow will automatically reduce when sequence is complete.

Move device downwards to release.

To change curl direction, rotate the barrel's cool tip.



Shaping



Smoothing brushes

Use Smoothing brush to brush from root to tip.

Tip:

For volume, face bristles outwards.



Turn brush inwards at the ends to create shape.



Volumising

Round volumising brush

The Round volumising brush has long fine bristles to direct air into the hair whilst giving body, creating tension to shape the hair as it dries.



Tip

Lift sections upwards as you dry to add volume. Wrap hair around and under the brush to shape the ends

The Blade concentrator


To create a smooth style.

Dry with a high-velocity blade of air for precision styling.

Focused airflow to create bends and flicks with a brush.




Once secured, the Blade concentrator can be rotated 360 degrees for ease when styling.



Tip

Angle attachment down the hair tress to avoid disruption and to create a smooth, aligned finish.




Smoothing

Dryer+Flyaway smoother

Rotate cool tip to select Smoothing mode.

Press against hair to switch airflow direction.




Use on dry hair to hide flyaways.

Position against hair until it attracts then slowly run down to tips.

For use on dry and straight hair.

How to use the contact bar

Position contact bar against the head until you hear a click and hair attracts. Run from root to tip to hide flyaways.



Diffusing

Wave+ Curl diffuser

Dome mode

Airflow is drawn into the dome to help enhance and smooth natural waves or curls.



Diffuse mode

Detachable prongs disperse airflow to the roots for textured, voluminous curls and coils.



Stretching

Wide-tooth comb

Comb hair downwards in small sections. Starting from the ends and working upwards towards the roots, until desired result is achieved.




Regular filter maintenance

Filter cleaning is overdue when the white LED starts flashing.


Ensure that you unplug your appliance from the mains electricity supply and allow to cool down before cleaning your filter.

The Dyson Airwrap i.d.™ multi-styler and dryer has highly tuned technology to give outstanding performance.

This technology needs to be kept free from dust and hair product residue. Maintenance is required to maintain performance.



Filter mesh



Filter cleaning brush




Filter cage

Step 1

Slide the filter cleaning brush over the cable and onto the filter cage.

Using a rotating action, clean the filter cage thoroughly.


Remove the filter cleaning brush.



Step 2


Hold the handle of your appliance and pull the filter cage downwards, onto the cable.

Gently pull open the filter cage and slide it off the cable.



Step 3

Wash the filter cage under a warm, running tap.





Step 4
Shake the filter cage to remove the majority of the excess water, then leave to dry naturally.

Step 4
Shake the filter cage to remove the majority of the excess water, then leave to dry naturally.

Step 5
Using a rotating and up and down action, clean the filter mesh with the filter cleaning brush until all the debris has been removed.

Step 5
Using a rotating and up and down action, clean the filter mesh with the filter cleaning brush until all the debris has been removed.

Do not use water or chemicals to clean the filter mesh.



Step 6
Gently pull the filter cage open and slide it onto the cable.

Step 6
Gently pull the filter cage open and slide it onto the cable.

Slide the filter cage towards the handle and twist until it snaps into place.

