

SIMPLE MANUAL

Wireless Sound Bar

Please read this manual carefully before operating your set and retain it for future reference.

To view the instructions of advanced features, visit http://www.lg.com and then download Owner's Manual. Some of the content in this manual may differ from your unit.

MODEL

SN5R




2107_Rev01

www.lg.com Copyright © 2021 LG Electronics Inc. All Rights Reserved.




Front Panel



Rear Panel

─/+ (Volume)····· Adjusts volume.



DC IN: Connect to the AC adapter.

OPTICAL IN Connect to an optical device.

HDMI IN Connect to device with HDMI OUT.

HDMI OUT (TV ARC) Connect to a TV.

USB (Service only) S/W download connector.

Make sure to properly align and connect the optical cable; improper alignment may cause damage to the jack.

Subwoofer Connection


Place the wireless subwoofer near the sound bar and follow steps below.

- Connect the power cord of the sound bar and the wireless subwoofer to the outlet.
- 2 Turn on the sound bar.
 - The sound bar and wireless subwoofer will be automatically connected. The subwoofer's green LED turns on.

Manual Subwoofer Connection

If the subwoofer does not make sound, try to connect manually.

- Press PAIRING on the rear of the wireless subwoofer.
 - The green LED on the rear of the wireless subwoofer blinks quickly.
 (If the green LED does not blink, press and hold the **PAIRING**.)
- 2 Turn on the sound bar.
 - Pairing is completed. The green LED on the rear of the wireless subwoofer turns on.




TV Connection

Connect the sound bar and TV using Optical (A) or HDMI ARC (B).


Optical Connection

- Connect the sound bar to the TV using Optical cable.
- Set up [External Speaker (Optical)] on your TV setting menu.



B HDMI (ARC) Connection


- Connect the sound bar to the TV using HDMI cable.
- Set up [External Speaker (HDMI ARC)] on your TV setting menu.



- HDMI connection is unavailable if your TV does not support HDMI ARC.
- If this unit is connected by OPTICAL and ARC at the same time, the ARC signal has a higher priority.

Additional Device Connection

1 Connect to the external device like as follow.




2 Set the input source by pressing F repeatedly.

Remote control



Replacement of Battery



M/M: Skip M: Play/Pause

 Bluetooth connection lock (BT LOCK): Select the Bluetooth function by pressing F repeatedly.
 Long press II and press it again to limit Bluetooth connection to only BT and LG TV.

SOUND EFFECT: Selects a sound effect mode.

- TV remote: Long press SOUND EFFECT and press it again to use TV remote control.
- *): Turns on or off the Night time mode.
- ①: Displays the information of a file, an input source or connected **Bluetooth** device name.
- **Auto Power ON/OFF:** Long press ① and press it again.
- **↓†↓**: Adjusts sound level of each speaker.
- **Surround sound:** Long press **!** and press it again.
- *: This button is not available.

Additional Information

Specification

	Refer to the main label.
Power consumption	Networked standby: 1.0 W
	(If all network ports are
	activated.)
AC adapter	Model: DA-50F25
	Manufacturer: Asian Power
	Devices Inc.
	• Input : 100 - 240 V ~
	50 - 60 Hz
	• Output : 25 V === 2 A
	• Model: MS-Z2000R250-
	050D0-P
	Manufacturer : MOSO POWER
	SUPPLY TECHNOLOGY CO., LTD.
	• Input : 100 - 240 V ~
	50/60 Hz
	• Output : 25 V === 2 A
Dimensions (W x H x D)	Approx.
	890.0 mm X 57.0 mm X
	85.0 mm With foot
Amplifier (Total RMS Output	
	520 W RMS
power)	

Design and specifications are subject to change without notice.

-(!)

Rear Surround sound

Wireless Rear Speakers Kit included for real surround sound. (SPJ4M-S)

How to disconnect the wireless network connection or the wireless device

Set up the AUTO POWER ON/OFF function to off and turn off the unit.

OPEN SOURCE SOFTWARE NOTICE INFORMATION

To obtain the source code under GPL, LGPL, MPL, and other open source licenses, that is contained in this product, please visit http://opensource.lge.com. In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to opensource@lge.com.

This offer is valid for a period of three years after our last shipment of this product. This offer is valid to anyone in receipt of this information.

Declaration of Conformity



Hereby, LG Electronics declares that the radio equipment type Wireless Sound Bar is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

http://www.lg.com/global/support/cedoc/cedoc# For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.











Российская Федерация

Импортер ООО "ЛГ Электроникс Рус"

Адрес импортера: 143160 Российская Федерация, Московская область, Рузский район, сельское поселение

Дороховское, 86 км. Минского шоссе, д.9

Адрес производителя : ЛГ Электроникс (Хужоу) Инк., завод Хатаи

516006, Китай, пров. ГуанДонг, г. Хужоу, Промышленная зона Жонгкай, Индустриальный парк Хутаи, ХуФенг Донг Уи Роуд, 13.

Сделано в Китае

Україна

Вироблено в: ЛГ Електронікс (Хужоу) Інк., завод Хатай

516006, Китай, пров. ГуанДонг, м. Хужоу, Промислова зона Жонгкай,

Індустріальний парк Хутай, ХуФенг Донг Уі Роуд, 13.

Қазақстан Республикасы

Импорттаушы АҚ "ЭЛ Джи Электроникс Алматы Қазақстан", 050061, Алматы қ., Көкорай көшесі, 2А/9

Өндірушінің мекенжайы: LG Electronics(Huizhou) Inc. Huitai Factory

516006, Қытай, ГуанДонг ауданы, Хужоу қаласы, Жонгкай өнеркәсіптік аймағы,

Хутай Индустриялық саябағы, ХуФенг Донг Уи Роуд, 13.

Қазақстан Республикасы территориясында тұтынушылардан келіп түскен талаптар мен ұсыныстарды қарайтын және тауарды жөндеу мен техникалық қызмет көрсететін ұжым:

АҚ «Эл Джи Электроникс Алматы Казақстан», 050061, Қазақстан Республикасы, Алматы қ., Көкорай көшесі, 2А/9. Басқа сервис орталықтары жайында мағлұматты "Тұтынушыға қызмет көрсету орталығына" телефон шалу арқылы білуге болады.

Қытайда жасалған



SIMPLE MANUAL

Wireless Rear Speakers Kit (Receiver)

Please read this manual carefully before operating your set and retain it for future reference.

To view the instructions of advanced features, visit http://www.lg.com and then download Owner's Manual. Some of the content in this manual may differ from your unit.

MODEL

SPJ4M-S




2107_Rev01

www.lg.com Copyright © 2021 LG Electronics Inc. All Rights Reserved.



1 Rear Speakers Connection

Speaker design and connection method may be different according to models.



- 1 Connect the speaker cables to rear speakers correctly.
- 2 Connect the Wireless Receiver and the rear speakers (Blue: left, Grey: right) with the speaker cables
- 3 Turn on the Surrond function to enjoy surround sound.

2 Wireless Receiver Connection

- 1 Connect the power cord of wireless receiver to the outlet.
- 2 Turn on the unit: The unit and wireless receiver will be automatically connected. The receiver's yellow - green LED turns on.


Wireless Receiver Connection Manually

If the rear speakers do not make sound, try to connect manually.

- 1 Press PAIRING button on the rear of the wireless receiver.
 - The yellow green LED on the wireless receiver blinks quickly.
- 2 Turn on the main unit.
- 3 Pairing is completed.
 - The yellow green LED on the wireless receiver turns on.

(T)

Set the distance between the sound bar and the wireless receiver as close as possible and keep them away from the device (ex. wireless router, microwave oven, etc.) over 1 m to prevent wireless interference.



Surround Sound On/Off

When you turn on surround function, you can enjoy magnificent surround sound for all the input sound source with rear speakers.

The initial setting for the surround function is OFF, turn the surround function ON to use it.

Surround On: Press and hold ## button on the remote control about 3 seconds and then press ## button repeateadly to select ON - SURROUND in the display window.

Surround Off: Press and hold ## button on the remote control about 3 seconds and then press 174 button repeateadly to select OFF - SURROUND in the display window.

Additional Information

Specification of Wireless reciever

Power requirement	Refer to the main label on the wireless receiver.
Power consumption	Refer to the main label on the wireless receiver.
Dimensions (W x H x D)	Approx. 60 mm x 220 mm x 175 mm

Design and specifications are subject to change without notice.

About Ferrite Core (Optional)



Declaration of Conformity



Hereby, LG Electronics declares that the radio equipment type Receiver is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

http://www.lg.com/global/support/cedoc/cedoc#

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.



Российская Федерация

Импортер ООО "ЛГ Электроникс Рус"

Адрес импортера: 143160 Российская Федерация, Московская область, Рузский район, сельское поселение Дороховское, 86 км. Минского шоссе, д.9

Адрес производителя : ЛГ Электроникс (Хужоу) Инк., завод Хатаи

516006, Китай, пров. ГуанДонг, г. Хужоу, Промышленная зона Жонгкай, Индустриальный парк Хутаи, ХуФенг Донг Уи Роуд, 13.

Сделано в Китае

Україна

Вироблено в: ЛГ Електронікс (Хужоу) Інк., завод Хатай

516006, Китай, пров. ГуанДонг, м. Хужоу, Промислова зона Жонгкай,

Індустріальний парк Хутай, ХуФенг Донг Уі Роуд, 13.

Қазақстан Республикасы

Импорттаушы АҚ "ЭЛ Джи Электроникс Алматы Қазақстан", 050061, Алматы қ., Көкорай көшесі, 2А/9

Өндірушінің мекенжайы: LG Electronics(Huizhou) Inc. Huitai Factory

516006, Қытай, ГуанДонг ауданы, Хужоу қаласы, Жонгкай өнеркәсіптік аймағы,

Хутай Индустриялық саябағы, ХуФенг Донг Уи Роуд, 13.

Қазақстан Республикасы территориясында тұтынушылардан келіп түскен талаптар мен ұсыныстарды қарайтын және тауарды жөндеу мен техникалық қызмет көрсететін ұжым:

АҚ «Эл Джи Электроникс Алматы Казақстан», 050061, Қазақстан Республикасы, Алматы қ., Көкорай көшесі, 2А/9. Басқа сервис орталықтары жайында мағлұматты "Тұтынушыға қызмет көрсету орталығына" телефон шалу арқылы білуге болады.

Қытайда жасалған