


MANUAL | QUICK START GUIDE

Corsair iCUE Link System

ICUE LINK ECOSYSTEM CONTROL CENTER



GETTING TO KNOW YOUR SYSTEM HUB



A. iCUE LINK active port

C. USB input

B. Power input

D. Tach output


PACKAGE CONTENTS

1




1x iCUE LINK System Hub





1x iCUE LINK Cable, 600mm


3






1x iCUE LINK Cable, 100mm

4



1x PCIe power cable, 150mm

5







1x USB cable, 300mm

SYSTEM HUB INSTALLATION


CONNECT THE SYSTEM HUB TO USB AND POWER




Connect the 6-pin micro-fit connector (4) into the power input (B) of the System Hub (1).



Connect the 6-pin PCIe connector (4) into a dedicated power cable from the power supply.



Connect the micro-USB cable (5) into the USB input (C) of the System Hub (1).



Connect the 9-pin USB 2.0 connector (5) into a USB 2.0 header on the motherboard.

CONNECT THE TACH CABLE (OPTIONAL) AND ICUE LINK DEVICES



If you are using an iCUE LINK CPU Cooler, connect the 2-pin, 1-wire tach cable into the System Hub (1). Connect the 3-pin



Connect your iCUE LINK devices to the System Hub (1) using the provided iCUE LINK cables (2,3). Use one of the two iCUE

connector into the CPU_FAN header on the motherboard.

LINK ports (A) of the System Hub (1) for this connection.

WARRANTY



iCUE LINK System Hub has a 2-year warranty.

LEGAL

© 2023 CORSAIR MEMORY, Inc. All rights reserved. CORSAIR and the sails logo are registered trademarks of CORSAIR in the United States and/or other countries. All other trademarks are the property of their respective owners. Product may vary slightly from those pictured.

POWER RATING

System Hub Output rating: 12Vdc 7A (per port)

Get special offers, exclusive product news, and event info straight to your inbox.

Enter your email

SIGN UP













SHOP

New Products

Special Offers

Corsair.com Exclusives

Where to buy

Certified Refurbished

Business Solutions

EXPLORE

PC Builder

CORSAIR Innovation

Design Your Loop

Best Gaming Accessories

Intel 14th Generation Upgrades

AMD AM5 Upgrades

DDR5 Memory

Ambassadors

CORSAIR

About

Investor Relations

Supply Chain Disclosure

Careers

Social Impact

Press Room

Contact Us

Explorer



SUPPORT

Terms of Sale

Downloads
Customer Support
Warranty
Shipping/RMA/Returns

Copyright © 1996 - 2024 CORSAIR. All rights reserved.

