



FCC ID: 2A5B0HQY002 IC ID: 28277-HQY003
MADE IN CHINA



MANUFACTURER

Shenzhen Ginto E-Commerce Co., Limited
Zoom 08 13F, Block b, Huihai square, Chuangye
road, Longhua street, Longhua Dist., shenzhen,
CHINA, 518000

support@truefree.com
www.truefree.com




Company: Qing UC(haftungsbeschränkt)
Address: Undinestr. 7, 12205 Berlin Germany



TANMET INT'L BUSINESS LTD.
9 Pantygraigwen Road, Pontypridd, Mid Glamorgan, CF37 2RR, UK
tanmetbiz@outlook.com


T2
WIRELESS EARBUDS

TRUEFREE



User Guide

Pairing




1. Open the charging case cover, and the left and right earphones will automatically turn on and enter the mutual pairing state. When the light on one earphone flashes red and blue alternately and the other earphone stays in blue, the two earphones are successfully paired, and they enter the pairing mode.
2. Turn on your device's Bluetooth and select TRUEFREE T2 from the Bluetooth list to complete the pairing.

English


Reset

1. Place the earphones back into the charging case, and make sure they are correctly placed.
2. With the charging case lid open, press and hold the button on the charging case for 10 seconds until the lights on the earphones flash red and blue alternately twice, the reset is complete.
3. Close the charging case lid and re-open it, the earphones are activated.




Wearing

1. Identify the left earphone and the right earphone.
2. Adjust the earphones to fit your ears.



English

Product Diagram



English

Touch Control

Power On	Auto: Open the charging case and the earphones turn on automatically Manually: Press and hold the multifunctional button for 1.5s when earphones are off
Power off	Auto: Place the earphones back into the charging case and close the case lid Manually: Press and hold the multifunctional button for 10s when earphones are on
Play/Pause	Double-tap on the multifunctional button
Volume-	Single-tap on the left multifunctional button
Volume+	Single-tap on the right multifunctional button
Next Track	Press and hold the right multifunctional button for 1.5s
Previous Track	Press and hold the left multifunctional button for 1.5s
Answer/ Hang Up a Phone Call	Double-tap on the multifunctional button
Reject a Phone Call	Press and hold the multifunctional button for 1.5s
Switch Between Two	Press and hold the multifunctional button for 1.5s
Active Calls	
Activate the Voice Assistant	Press the right multifunctional button for three times
Activate/Deactivate the Game Mode	Press the left multifunctional button for three times

English

Q&A

Q1: What does the indicator light of the charging case display?

1. The battery life of the charging case:

100%—50%	Green light
49%-10%	Yellow light
Less than 10%	Red light

2. Charging status of the charging case:


0%-20%	Red light flashes slowly
21%-69%	Yellow light flashes slowly
70%-99%	Green light flashes slowly
100%	Green light stays on



English

Q2: How to charge the charging case?

1. Connect the charging case to a Type-C charger. (The current does not exceed 1A).
2. If the earphones stay idle for an extended period, charge them at least every three months to prevent the battery from being damaged.



Q3: Why are the earphones still connected to the phone when they are put back to the charging case and the case lid is closed?

1. Check whether the charging case has battery power. If it has run out of battery, closing it will not disconnect the earphones from the device.
2. Make sure the earphones are properly placed in the charging case and the charging contacts on the earphones and charging case are all clean. Please use a soft cloth and a bit of alcohol to clean the contact points on the earphones and the charging case.

English

IC STATEMENT

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device

Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux

deux conditions suivantes :

- (1) Cet appareil ne doit pas causer d'interférences.
- (2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

IC: 28277-HQY003

HVIN: T2

FCC STATEMENT

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correct the interference by one or more of the following measures:

Reorient the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.