


526L Integrated Quad Door Refrigerator OIF4DF526PRO

Designed to Enhance
EST. 1981

omega



Introducing your new 526L Integrated Refrigerator



Control Panel

- A. Freezer Temperature Display
- B. Refrigerator Temperature Display
- C. Ultra Freeze Button
- D. Fast Freeze Button
- E. Temperature Adjustment Buttons
- F. Freezer Compartment Button
- G. Fridge Compartment Button
- H. Variable Temperature Zone Button
- I. Fast Chill Button
- J. Child Lock Button

Before Using Your Appliance

- Remove all packaging, including foam backing and tape securing shelves and door trays.
- Before use, clean the unit with a warm, soapy cloth, and dry thoroughly.
- Switch on the appliance using the Power Button (for location, refer to page 8 of the User Manual).

Details

Product Dimensions (W, D, H mm): 962 × 572 × 1996
Warranty Period: 3 Years

Operating Advice

- The default temperature of the fridge is set to 5°C.
- The default temperature of the freezer is set to -18°C.
- The default temperature of the variable zone is -0°C
- To adjust the temperature, press the Fridge, Freezer or Variable Zone Button to cycle through the available set temperatures.
- Fast Freeze: The compressor runs continuously automatically deactivating after 24 hours of operation or when the freezer temperature reaches -28°C.
- Fast Chill: The fridge compartment rapidly reaches the set temperature and operates for 150 minutes.
- Child Lock: Press and hold this button for 3 seconds to lock or unlock the controls. When the icon is off, the controls are unlocked. When the icon is on, the controls are locked.

Refer to the User Manual, pages 19–20, for a detailed guide on operating your appliance.

Support

Telephone: 1300 11 HELP (4357)
Email: support@residentiagroup.com.au

