

M8说明书 80克书纸 10页5开双面印刷

120x75 (mm)

MODEL: M8 WIRELESS BLUETOOTH SPEAKER 无线蓝牙音响 用户说明书 USER MANUAL	前言 尊敬的客户：感谢您购买此产品，为了能够更进一步的了解产品，使用前请仔细阅读本说明书，祝你体验愉快！ 请保存此说明书以供后面参考！ 包装内容 1* M8主机音响 1* Type-C充电线 1* 3.5毫米AUX外接音频线 1* 用户说明书	按键功能详解 ① 挂绳扣 ② 电源键: 长按 开/关机 短按 播放/暂停 ③ 蓝牙/电话键: 长按 强制断开蓝牙连接 短按 切换蓝牙/AUX模式 接听挂断电话 ④ 加号键: 短按 音量加 长按 下一曲 ⑤ 减号键: 短按 音量减 长按 上一曲 ⑥ 灯光键: 短按 打开/关闭灯光 ⑦ TWS配对键: 短按 开启/取消 TWS互联 长按 清除配对 ⑧ 充电指示灯/移动电源指示灯 ⑨ 蓝牙指示灯 ⑩ TWS指示灯 ⑪ AUX接口 ⑫ TF卡插槽孔 ⑬ Type-C接口 ⑭ 移动电源输出接口 操作说明 (1) 蓝牙模式 1、开机后，进入蓝牙模式，蓝牙灯闪烁，打开您的蓝牙，设备搜索到“M8”选择连接，连接成功，音响提示“蓝牙已连接”蓝牙灯常亮，即可播放音乐。 2、蓝牙连接成功后使用手机拨打电话，音响进入蓝牙免提通话。来电短按“⑥”接听，长按拒接。 (2) AUX音频输入模式 请将3.5mm音频线连接到手机/电脑的耳机输出口，短按“⑥”键切换到AUX模式，音响提示“外接音源模式”即可播放音乐。 ※因多电脑的USB接口供电能力不能满足音响工作需求，建议使用AUX连接电脑播放音乐时，不要使用电脑USB口给音响同步充电。 (3) TF卡模式 请将TF卡插入音响，音响会自动切换至并语音提示“读卡音乐模式”自动播放卡内音乐，内存最大支持 32G TF卡。 (此功能仅适用于部分机型，详情请咨询当地经销商。) (4) TWS无线立体声播放 将两台M8开机，进入蓝牙模式后，短按其中一台“⑦”键TWS灯闪烁，自动搜索另一台音响进行组队，组队成功，两
---	---	--

操作说明

台音响转换成左右声道。重复蓝牙连接操作将音响连接手机，播放手机音乐即可实现无线立体声音效。
注：此功能需要两台音响，并都开机在蓝牙模式才能使用。
在TWS配对前没有做任何何设备进蓝牙连接。
在TWS互联状态，短按其中一台音响“⑦”键即可取消互联。

左声道(主机)

右声道(副机)

(5) 炫酷派对灯光
开机默认开启派对灯光，短按“⑥”键开启/关闭灯光。

(6) Type-C快速充电
※请勿使用未通过安规认证的电源适配器。
※建议使用输出为5V-2A的电源适配器进行充电。
1、音响提示“设备电量不足”，请尽快为音响充电。
2、音响支持自适应充电，根据外接电源适配器功率自动选择充电电流，当使用电脑USB接口为本音响充电，充电电流小，充电时间会比较长。
3、充电时红灯常亮，充满绿灯常亮。
温馨提示：
1、本产品是基于生活防水，可以正常冲洗切勿将音响长期浸泡水中。（**如因进水导致音响功能故障，我司留有最终解释权**）
节能省电：
在下列情况下音响将自动关机节省电量。
1、蓝牙模式下，等待配对持续二十分钟无设备连接蓝牙。
2、任意模式下，短按“⑥”暂停二十分钟后无操作将自动关机，再次开机请长按电源键。
(7) 移动电源输出
※禁止将同一条充电线的USB接口和Type-C接口同时插入音响。
※音响充电时移动电源功能是禁止状态，两种状态不能同时存在。
1、USB-A输出：5V/1A(音响开机时移动电源功能才有作用)。

操作说明

2.开机后将标准USB线插入移动电源输出口，另外一端连接手机，此时移动电源指示灯呈绿色状态，充满电绿灯熄灭。
3.当在使用音响对手机充电过程中将音响关机，此时音响会进入待机状态，移动电源正常对外充电，长按开机键唤醒音响。

技术参数

蓝牙版本	5.0	产品重量	865克	额定功率	40W
充电电压	5V/2A	电池容量	7200mA		

疑难解答

1、蓝牙无法连接或播放音乐没有声音怎么办？
请先确认音响是否处于蓝牙模式，再确认您的蓝牙设备是否支持蓝牙功能并将其打开.检查音响是否处于蓝牙搜索状态，如果周边蓝牙设备太多，可能会造成搜索困难，请关闭其他蓝牙设备。
2.TF卡播放没有反应怎么办？
请确认TF卡有无质量问题，并检查卡中音频文件是否为MP3播放格式，如果以上问题均排除，则可能是TF卡兼容性问题，可将TF卡格式化成为FAT32格式，或者尝试更换其他TF卡。

PREFACE Dear customer: Thank you for purchasing the M8 Bluetooth Speaker, for your better user's experience please read the user manual carefully before use. Enjoy the music journey! Please keep this user manual for your later references! PACKAGE CONTENT 1* M8 Main device 1* Type-C cable 1* 3.5mm Aux in cable 1* User Manual	KEY FUNCTION DEFINITION ① Strap hook ② Power: Long press Turn on/off Short press Play/Pause ③ Bluetooth/Phone: Long press force to disconnect Bluetooth connection Short press switch Bluetooth/ Aux in mode Answer/Hang off phone call ④ Plus: Short press to increase volume Long press to next track ⑤ Minus: Short press to decrease volume Long press to previous track ⑥ Lights key: Short press turn on/off lights ⑦ TWS pairing: Short press only/cancel TWS connection Long press to clear away TWS pairing ⑧ Charging light/Power bank light ⑨ Bluetooth light ⑩ TWS light ⑪ AUX interface ⑫ TF card slot ⑬ Type-C interface ⑭ Power bank output interface OPERATION INSTRUCTION (1) BLUETOOTH MODE 1.Turn on speaker enter into bluetooth mode,the bluetooth light starts to flash.Open the bluetooth on your device search for "M8" and connect to your speaker.If it's connected successfully,you will hear a prompt tone that "device paired". The bluetooth light is always on, now you can play music on your device by bluetooth. 2.When the bluetooth is connected successfully and you make calls with phone, the voice will automatically enter into the bluetooth hands-free mode.Short press "⑥" key to answer incoming call.Long press to reject call. (2) AUX IN MODE Please connect 3.5mm audio cable to the headphone of the phone/computer output interface, short press "⑥" key switch to AUX in mode.When you hear a prompt tone"AUX in mode", then you can play music. ※ Due to the lower power supply capability,most computer's USB interface can not meet speaker's operational requirements.It is not recommended to use the computer's USB for charging synchronously when you play music in the AUX in mode while connecting computer. (3) TF CARD PLAY Please insert TF card in speaker,the speaker will switch mode automatically with a prompt tone."TF card mode", the speaker will play music saved in card automatically. TF card memory maximum is 32G. (This mode is only apply to some models, please consult local dealer for details.) (4) TWS STEREO SOUND PLAY Turn on two M8 speakers enter into bluetooth mode. Short press "⑦" button of one speaker. TWS light starts to flash, the speaker will automatically search the other for TWS connection,if they connected successfully, two speakers will switch into left and right channels automatically. Repeat the bluetooth connection operation and connect to phone,
---	---

OPERATION INSTRUCTION

If they connected successfully ,music will play on the speaker shows dual stereo sound effect.
Note:This function requires two M8 speakers,male sure both are turned on and in the bluetooth mode.
No bluetooth connection to any other devices before TWS pairing.
When TWS is connected, short press "⑦" key of one speaker to cancel the

Left channel
(Main Speaker)

Right channel
(Auxiliary Speaker)

(5) COOL PARTY LIGHTS
Party lights on is defaulted setting when you turn on speaker, Short press "⑥" key to turn on/off lights.

(6) TYPE-C QUICK CHARGE
※ Do not use power adapter that has not been certificated by safety certification.
※ Power adapter with output 5V-2A is recommended for charging.
1.When you hear a prompt tone "Out of battery",Please charge speaker as quickly as possible.
2.This speaker supports self-adaption charging .It's able to choose charging current automatically according to the external rated power of the adapter. When charging by USB interface on computer, the current is smaller and it takes longer time to complete charging.
3. When speaker is charging, the power light is red and always on. When speaker is fully charged, the power light is green and always on.
Kindly tips:
This product is waterproof on daily basis conditions, and it can washes normally. Do not soak the product in water for a long time!(If the product malfunction due to water ingress, our company reserves the right of final Explanation).
Energy saving:
The speaker will automatically shut down to save power under below circumstances.
1. In bluetooth mode, after 20 minutes waiting for no device pairing.
2. In any modes, short press "⑥" key pause for 20 minutes without any operation the speaker will shut down automatically. Please long press the power key to turn it on again.

(7) POWER BANK OUTPUT
※ The USB and Type-C interfaces of the same charging line are forbidden to be inserted into the speaker simultaneously.

OPERATION INSTRUCTION

※ The function of power bank is forbidden when the speaker is charging. Both states can not exist at the same time.
1.USB-A OUTPUT - 5V/1A(Power bank function only works when speaker is turned on) .
2.Turn on speaker insert the standard USB cable into the output interface of power bank, connect the other end to the mobile. At this time the power bank indicator is green, the green indicator will be off after mobile being fully charged.
3.Turn off speaker in the process of using speaker to charge the mobile, speaker will stand by, power bank function works normally, and speaker can be awakened by long press the power key.

TECHNICAL PARAMETERS

Bluetooth version	5.0	Battery capacity	7200mAh
Charging voltage	5V/2A	Rated power	40W
Product weight	865g		

TROUBLE SHOOTING

1.Can not connect to bluetooth or no sound when playing music?
Please make sure the speaker is in bluetooth mode and also make sure your device supports bluetooth function and bluetooth has already been turned on searching for devices. Check if there are too many bluetooth devices around which might bring difficulties of the searching process. Please turn off other bluetooth device.

2.What if TF card doesn't respond ?
Please make sure TF card is in good quality and check whether the audio file is MP3 playing format, if all problems above are excluded , it might be TF card compatibility issue, you can consider of formatting TF card to FAT32 or change a different TF card.

V.1.0.0

WWW.WISEPNT.COM

制造商：深圳市智康科技有限公司

地址：中国广东省深圳市龙岗区六约社区勤富路38号
保税泰智汇广商B902

Manufacturer:
Shen zhen ZhiQ Technology Co., Ltd.
Address:
8802 Baochengtai Square, No.38 QinFu road, Liuxue Community, Henggang
Street, Longgang District, Shenzhen, China

FC CE UK RoHS

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.