

LIVING ROOM CHAIRS 6151-4380

NOTE:

Please read carefully before use and keep for future reference

Tell Free(US): 3235971109

Website: www.mcombo.com Amazon sold by: MCombo

Warranty Claim: sales@mcombo.com

Sales & Technical Questions: sales@mcombo.com sales@exacme.com




CONGRATULATIONS!


Mcombo Living Room Chairs - a name synonymous with classic design and the carrier of value and quality. Our products are directly from factory and eliminated the cost of middlemen. The Living Room Chairs is a high-quality shading solution to enhance comfortable feelings as you try to enjoy the nice day.


WARRANTY


- All warranties are to the original purchaser from MCOMBO ONLY ®
- MCOMBO [®] will replace the defective parts or send replacement item provided that the warranty parts have not been subjected to misuse, abuse or improper service by the consumer, for example, damaged wire arising in consequence of negligence or improper operation.
- MCOMBO [®] All of recliners come with a 30-day return/replace policy. During this time, we will cover the shipping cost of return and replacement for defective and damaged item, through provide pre-paid return label or pick up service for customer's convenience.


PARTS LIST






















Please remove all protective foam




Step 1


Unfold the folding Chair Frame **#B** according to the direction shown in the picture.

Step 2

Use 2 Clevis Pins **#H** to attach chair back to the chair seat according to the direction shown in the picture.

Insert Cotter Pins #I into the hole in Clevis Pins #H to fasten Clevis Pins #H.







Step 3

Pull up the zipper on Back Cushion **#A** and put Back Cushion **#A** on the Chair Back.


Step 4
Pull down the zipper on Back Cushion #A
and stick remaining fabric of Back Cushion
#A to Velcro under the Seat.





Step 5
Use 4 Screws #F to fix Seat Plate #C under the Chair Seat with Allen Wrench #G.

Step 6
Insert Spin Axis #D into holes in Chair Base
#E and Seat Plate #C respectively.





Congratulations!

Now you can relax your body on this chair and even decorate your living room.

KINDLY REMINDER

If you have any questions about the product or use, please feel free to contact sales@mcombo.com